

CE

MADE  
IN  
USA



# User's Guide

*Shop on line at*

**omega.com<sup>®</sup>**

Ω OMEGA<sup>®</sup>

[www.omega.com](http://www.omega.com)

e-mail: [info@omega.com](mailto:info@omega.com)

[www.omega.com/software](http://www.omega.com/software)

## **MICROMEGA<sup>®</sup>** **CN77000 Series Controller**



**OMEGAnet® On-Line Service**  
**www.omega.com**

**Internet e-mail**  
**info@omega.com**

### **Servicing North America:**

**USA:** One Omega Drive, P.O. Box 4047  
ISO 9001 Certified Stamford CT 06907-0047  
TEL: (203) 359-1660  
FAX: (203) 359-7700  
e-mail: info@omega.com

**Canada:** 976 Bergar  
Laval (Quebec) H7L 5A1  
TEL: (514) 856-6928  
FAX: (514) 856-6886  
e-mail: info@omega.ca

### **For immediate technical or application assistance:**

**USA and Canada:** Sales Service: 1-800-826-6342 /  
1-800-TC-OMEGA®  
Customer Service: 1-800-622-2378 /  
1-800-622-BEST®  
Engineering Service: 1-800-872-9436 /  
1-800-USA-WHEN®  
TELEX: 996404 EASYLINK: 62968934  
CABLE: OMEGA

**Mexico and  
Latin America:** TEL: (001)800-TC-OMEGA®  
FAX: (001) 203-359-7807  
En Español: (001) 203-359-7803  
e-mail: info@omega.com.mx

### **Servicing Europe:**

**Benelux:** Postbus 8034, 1180 LA Amstelveen, The Netherlands  
TEL: +31 20 3472121  
FAX: +31 20 6434643  
Toll Free in Benelux: 0800 0993344  
e-mail: nl@omega.com

**Czech Republic:** Rudé armády 1868, 733 01 Karviná 8  
TEL: +420 69 6311899  
FAX: +420 69 6311114  
e-mail: czech@omega.com

**France:** 9, rue Denis Papin, 78190 Trappes  
TEL: +33 130 621 400  
FAX: +33 130 699 120  
Toll Free in France: 0800406342  
e-mail: france@omega.com

**Germany/Austria:** Daimlerstrasse 26, D-75392 Deckenpfronn, Germany  
TEL: +49 7056 9398-0  
FAX: +49 7056 9398-29  
Toll Free in Germany: 0800 639 7678  
e-mail: germany@omega.com

**United Kingdom:** One Omega Drive  
ISO 9002 Certified River Bend Technology Centre  
Northbank, Irlam Manchester M44 5BD United Kingdom  
TEL: +44 161 777 6611  
FAX: +44 161 777 6622  
Toll Free in England: 0800 488 488  
e-mail: sales@omega.co.uk

It is the policy of OMEGA to comply with all worldwide safety and EMC/EMI regulations that apply. OMEGA is constantly pursuing certification of its products to the European New Approach Directives. OMEGA will add the CE mark to every appropriate device upon certification.

The information contained in this document is believed to be correct, but OMEGA Engineering, Inc. accepts no liability for any errors it contains, and reserves the right to alter specifications without notice.

**WARNING:** These products are not designed for use in, and should not be used for, patient-connected applications.



This device is marked with the international caution symbol. It is important to read the Setup Guide before installing or commissioning this device as the guide contains important information relating to safety and EMC.

# To Order Model CN77000 SERIES CONTROLLER (Specify Model Number)

## PROCESS CONTROLLER, DUAL DISPLAY FOR THERMOCOUPLE, RTD, VOLTAGE OR CURRENT INPUTS IN A 1/16 DIN CASE

Model No. Description	Model No. Description cont.
<p>CN77 Dual displays for simultaneous display of measured value and setpoint. Selectable preset tune, adaptive tune, autotune, PID, PI, PD control modes. The dual control outputs can be configured for a variety of control and alarm applications such as heat, heat/cool, heat/alarm, cool or cool/alarm. The ramp to setpoint feature allows the user to define the rate of rise to setpoint, minimizing thermal shock to the load during start-up. Maximum ramp time 99.59 (HH.MM), Soak: 00.00 to 99.59 (HH.MM), Damping: 1 to 8 in unit steps. Input types J,K,T,E,R,S,B,N,J-DIN°C, RTD 100Ω 0.00385, 100Ω &amp; 1kΩ 0.00392, 0 to 20 mA, 4 to 20 mA, 0 to 100mV, 0 to 1V, 0 to 10Vdc. Alarm 1 output includes SPST relay, 3A @ 120Vac, 3A @ 240Vac.</p> <p>NOTE: The Controller must be ordered completely configured. Options are not field installable.</p>	<p>[ ] OPTIONAL OUTPUTS            * none (no entry required)            -A2 SPST relay, 3A@ 120Vac, 3A @ 240Vac (Alarm 2)            -C2 Isolated RS232, 300 to 19.2k baud            -C4 Isolated RS485, 300 to 19.2k baud            -PV Isolated Analog Output            -RSP Remote Setpoint Selection</p>
<p>[ ] CASE TYPE            R3 NEMA 1, 1.89 x1.89" (48 x 48mm) bezel and 1.75" ROUND cutout            R5 NEMA 1, 2.1 x 2.1" bezel and 1.75" ROUND cutout            3 NEMA 12 bezel for 1/16 DIN panel cutout 45mm x 45mm (1.772 x 1.772")            5 NEMA 4 bezel for 1/16 DIN panel cutout 45mm x 45mm (1.772 x 1.772")</p>	<p>[ ] POWER SUPPLY            * 90 to 240 Vac/dc, 50 to 400Hz (no entry required)</p>
<p>[ ] CONTROL OUTPUT #1 (Direct or Reverse Acting)            2 Solid State Relay SSR : 1A @ 120/240Vac continuous            3 Relay: Form "C" 5A @ 120Vac, 3A @ 240Vac            4 Pulsed 10Vdc @20mA (for use with external SSR)            5 Non-Isolated 1 to 10Vdc or 0-20mA @500Ω max</p>	<p><u>NEMA 1/UL Type 1:</u> Intended for indoor use, to provide a degree of protection against contact with the enclosed equipment and against limited amount of falling dirt.</p> <p><u>NEMA 4/UL Type 4:</u> Intended for indoor use, to provide a degree of protection against splashing water, windblown dust and rain, and hose directed water and undamaged by the formulation of ice on the enclosure. <u>Testing-Hosedown:</u> Enclosure is subjected to a stream of water from a hose which has a 1" diameter nozzle and which delivers at least 65 gallons per minute from a distance of 10 to 12 feet for a minimum of 5 minutes.</p>
<p>[ ] CONTROL OUTPUT #2 (Direct or Reverse Acting)            0 Insert "0" if second output is not desired            2 Solid State Relay SSR: 1A @ 120/240Vac continuous            3 Relay: Form "C" 5A @ 120Vac, 3A @ 240Vac            4 Pulsed 10Vdc @20mA (use for external SSR)</p>	<p><u>NEMA 12/UL Type 12:</u> Intended for indoor use, to provide a degree of protection against circulating dust, falling dirt, and dripping non-corrosive liquids. <u>Testing-Drip:</u> Enclosure is subjected to a drip pan which produces both splashing and dripping. <u>Testing-Atomized Water:</u> Enclosure is subjected to a spray of atomized water by using a nozzle that produces a 3" round diameter spray, 12" from enclosure. The air pressure is at 30psi.</p> <p>For harsh environments, we recommend installation of the controller for square panel cutouts.</p>

### Ordering Examples:

- 1.) **CN77R322-C2** is a NEMA 1 bezel case with 1.75 inch round hole mounting adaptor, dual SSR control outputs and RS232 communications output.
- 2.) **CN77330** is a NEMA 12 bezel case with 1/16 DIN mounting and single Relay control output.
- 3.) **CN77544-A2** is a NEMA 4 bezel case with 1/16 DIN mounting, dual pulse control outputs, and a SPST 3A Alarm relay.



## NOTES

---

---

# TABLE OF CONTENTS



---

## Part 1: Introduction

1.1	Safety Considerations .....	1
1.2	Before You Begin.....	2

## Part 2: Setup

2.1	Mounting the Controller.....	4
2.2	Front Panel View .....	7
	<i>Front Panel Annunciators .....</i>	7
2.3	Rear Panel View.....	8
	<i>Rear Panel Connector Labels .....</i>	9
2.4	Mechanical Installation .....	10
	<i>Dip Switch Configuration .....</i>	10
	<i>Dip Switch Settings.....</i>	11
2.5	Electrical Installation .....	12
	<i>Input Connection Examples .....</i>	13
2.5.1	Thermocouple.....	13
2.5.2	Two/Three/Four Wire RTD .....	14
2.5.3	Process Current .....	15
2.5.4	Process Voltage .....	15



# TABLE OF CONTENTS

---

## **Part 3: Operation: Configuration Mode**

<b>3.1</b>	<b>Introduction .....</b>	<b>16</b>
	<i>Turning Your Controller on for the First Time .....</i>	<i>16</i>
	<i>Function in Configuration Mode.....</i>	<i>17</i>
<b>3.2</b>	<b>Menu Configuration .....</b>	<b>18</b>
	<i>ID Number .....</i>	<i>19</i>
	<i>Set Points .....</i>	<i>20</i>
	<i>Input Type (Thermocouple) .....</i>	<i>24</i>
	<i>Input Type (RTD) .....</i>	<i>25</i>
	<i>Input Type (RTD Value) .....</i>	<i>26</i>
	<i>Input Type (Process) .....</i>	<i>27</i>
	<i>Reading Configuration.....</i>	<i>29</i>
	<i>Alarm 1.....</i>	<i>33</i>
	<i>Alarm 2.....</i>	<i>36</i>
	<i>Loop Break Alarm .....</i>	<i>38</i>
	<i>Output 1 .....</i>	<i>42</i>
	<i>Output 2 .....</i>	<i>52</i>
	<i>Ramp &amp; Soak.....</i>	<i>58</i>
<b>3.3</b>	<b>Available Options.....</b>	<b>60</b>
	<i>Analog Output Option.....</i>	<i>61</i>
	<i>Communication Option .....</i>	<i>64</i>



**Configuration Mode Cont.**

*Command Formats* .....72  
*Reading Scale* .....86  
*Reading Offset* .....87  
*Remote Setpoint Option* .....88

**Part 4 Specifications.....91**

**List of Figures**

Figure 2.1 a. — Mounting the Square Mount Controller .....5  
 Figure 2.1 b. — Mounting the Round Mount Controller .....6  
 Figure 2.2 — Front Panel Display .....7  
 Figure 2.3 — Typical Rear Connector Label and Possible Labels of Different Models .....8  
 Figure 2.4 — Dip Switch Location .....10  
 Figure 2.5.1 — Power Wiring Hookup .....12  
 Figure 2.5.2 — Thermocouple Wiring Hookup .....13  
 Figure 2.5.3 — Two-wire RTD Hookup, Three-Wire RTD Hookup, Four -Wire RTD Hookup .....14  
 Figure 2.5.4 — Process Current Wiring Hookup .....15  
 Figure 2.5.5 — Process Voltage Wiring Hookup .....15  
 Figure 3.1 — Flowchart for ID and Set Point Menus .....18  
 Figure 3.2 — Flowchart for Input Type .....23  
 Figure 3.3 — Flowchart for Reading Configuration .....28



# TABLE OF CONTENTS

---

## List of Figures *Cont.*

Figure 3.4 — Flowchart for Alarm 1 and Alarm 2.....	32
Figure 3.5 — Flowchart for Loop Break.....	37
Figure 3.6 — Flowchart for Output 1.....	41
Figure 3.7 — Flowchart for Output 2.....	51
Figure 3.8 — Flowchart for Ramp & Soak.....	57
Figure 3.9 — Flowchart for Analog Output Option.....	61
Figure 3.10 — Flowchart for Communication Option.....	64
Figure 3.11 — Flowchart for Remote Setpoint.....	88

## List of Tables

Table 3.1 — Communication Commands.....	72
Table 3.2 — Command Letters and Index .....	76



## 1.1 Safety Considerations



This device is marked with the international caution symbol. It is important to read this manual before installing or commissioning this device as it contains important information relating to Safety and EMC (Electromagnetic Compatibility).

This instrument is a panel mount device protected in accordance with Class I of EN 61010 (115/230 AC power connections). Installation of this instrument should be done by qualified personnel. In order to ensure safe operation, the following instructions should be followed.



This instrument has no power-on switch. An external switch or circuit-breaker shall be included in the building installation as a disconnecting device. It shall be marked to indicate this function, and it shall be in close proximity to the equipment within easy reach of the operator. The switch or circuit-breaker shall meet the relevant requirements of IEC 947-1 and IEC 947-3 (International Electrotechnical Commission). The switch shall not be incorporated in the main supply cord.



Furthermore, to provide protection against excessive energy being drawn from the main supply in case of a fault in the equipment, an overcurrent protection device shall be installed.

- Do not exceed voltage rating on the label located on the top of the instrument housing.
- Always disconnect power before changing signal and power connections.
- Do not use this instrument on a work bench without its case for safety reasons.
- Do not operate this instrument in flammable or explosive atmospheres.
- Do not expose this instrument to rain or moisture.
- Unit mounting should allow for adequate ventilation to ensure instrument does not exceed operating temperature rating.
- Use electrical wires with adequate size to handle mechanical strain and power requirements. Install without exposing bare wire outside the connector to minimize electrical shock hazards.

### EMC Considerations

- Whenever EMC is an issue, always use shielded cables.
- Never run signal and power wires in the same conduit.
- Use signal wire connections with twisted-pair cables.
- Install Ferrite Bead(s) on signal wires close to the instrument if EMC problems persist.

**Failure to follow all instructions and warnings may result in injury!**

### ***Customer Service***

## **1.2 Before You Begin**

If you need assistance, please contact the nearest Customer Service Department, listed in this manual.

### ***Inspecting Your Shipment***


Remove the packing slip and verify that you have received everything listed. Inspect the container and equipment for signs of damage as soon as you receive the shipment. Note any evidence of rough handling in transit. Immediately report any damage to the shipping agent. The carrier will not honor damage claims unless all shipping material is saved for inspection. After examining and removing the contents, save the packing material and carton in the event reshipment is necessary.

### ***Manuals, Software:***

The latest Operation and Communication Manual as well as free configuration software are available from **the website listed in this manual or on the CD-ROM enclosed with your shipment.**

## TO DISABLE OUTPUTS

Standby mode is useful during setup of the controller or when maintenance of the system is necessary. When the controller is in standby, it remains in the ready condition but all outputs are disabled. This allows the system to remain powered and ready to go.



When the controller is in "RUN" Mode, **push ENTER twice to disable all outputs and alarms.**

It is now in "STANDBY" Mode. Push ENTER once more to resume "RUN" Mode.


**Tip**

**PUSH ENTER TWICE** to disable the system during an **EMERGENCY**.

## 2.1 Mounting the Controller

**Note**

If necessary, the rear connector assembly may be removed from the main case for wiring (see Figure 2.1a for Square Mount, Figure 2.1b for Round Mount).



## Square Mount Micro Controller Mounting Instructions





Figure 2.1a — Mounting the Square Mount Controller

## Round Mount Micro Controller Mounting Instructions

1. Separate the display from the meter by squeezing the case (where shown) and then unplugging the cable from the meter.
2. Slide the retainer over the rear of the case, but do not engage serrations on case.
3. Pass the cable (from the display) thru a  $1\frac{3}{4}$ " diameter hole in the mounting panel and connect to the meter (take care to center the connector on the mating pins). While squeezing the case, press the display and meter squarely together until they connect.
4. Check the display and gasket for proper alignment, then slide the retainer tight against the backside of the mounting panel.



**Figure 2.1b — Mounting the Round Mount Controller**

## 2.2. Front Panel View




Figure 2.2 Front Panel Display

### Front Panel Annunciators

<b>SP1</b>	OUT1/Setpoint 1 indicator.
<b>SP2</b>	OUT2/Setpoint 2 indicator.
<b>AL1</b>	Alarm 1 indicator.
<b>AL2</b>	Alarm 2 indicator.
<b>°C</b>	°C unit indicator.
<b>°F</b>	°F unit indicator.
<b>PV</b>	Upper display shows the Process Value
<b>SV</b>	Lower display shows the Setpoint Value
<b>MENU</b>	Changes display to Configuration Mode and advances thru menu items*
<b>▲/MAX</b>	Used in program mode and peak recall*
<b>►/MIN</b>	Used in program mode and valley recall*
<b>ENTER</b>	Accesses submenus in Configuration Mode and stores selected values*

\* See Part 3 Operation: Configuration Mode

## 2.3. Rear Panel View




Figure 2.3 Typical Rear Connector Label and Possible Labels of Different Models




**Rear Panel Connector Labels**

<b>POWER</b>	AC Power Connector: All models
<b>INPUT</b>	Input Connector: All models TC, PR (Process) RTD
<b>ALARM 1</b>	ALARM 1 relay SPST, programmable: All models
<b>OUTPUT 1</b>	Control Output 1: Based on one of the following models. Relay SPDT            Voltage and Current Solid State Relay    Pulse
<b>OUTPUT 2</b>	Control Output 2: Based on one of the following models: Relay SPST Normally Open Solid State Relay Pulse
<b>OPTION</b>	Based on one of the following models: RS-232C                Isolated Analog Out RS-485                 Alarm 2 Relay SPST, programmable Remote Setpoint

### Dip Switch Configuration

## 2.4. Mechanical Installation


The settings of the DIP switch must be verified or set to comply with your selection at the Input/Type menu (see Section 3.0 for Input/Type). The DIP switch is accessible through an opening on the side of the case. After carefully removing the controller from the case, see Section 2.1 for instructions, locate the dip switch (see Figure 2.4) and set the switches according to the following tables.




**Figure 2.4 Dip Switch Location — switch settings are shown in OFF position**

# Dip Switch Settings


**Thermocouple**




**RTD 100**




**RTD 500/1k ohm**




**Process 20mA**




**Process 100mV**



**Process 1V**



**Process 10V**






Figure 2.5.1 Power Wiring Hookup

**Note**

The Safety European Standard EN61010-1 for measurement, control, and laboratory equipment requires that fuses must be specified based on IEC127. This standard specifies for a Time-lag fuse, the letter code "T". The above recommended fuses are of the type IEC127-2-sheet III. Be aware that there are significant differences between the requirements listed in the UL 248-14/CSA 248.14 and the IEC 127 fuse standards. As a result, no single fuse can carry all approval listings. A 1.0 Amp IEC fuse is approximately equivalent to a 1.4 Amp UL/CSA fuse. It is advised to consult the manufacturer's data sheets for a cross-reference.

## 2.5. Electrical Installation

### POWER CONNECTION EXAMPLES

The figure below shows the power wiring hookup.



**Use copper conductors only for power connections**



**The Protective Conductor terminal must be connected for safety reasons.**


Fuse	Connector	Output Type	115 Vac	230 Vac
Fuse 1	Output 1	Relay	5 A(T)	3 A(T)
Fuse 2	Output 1	Relay	5 A(T)	3 A(T)
		SSR	0.5 A(T)	0.5 A(T)
Fuse P	Power	N/A	100 mA(T)	100 mA(T)
Fuse A	Alarm 1/2	Relay	3 A(T)	3 A(T)

**Note:** Values shown are minimum recommendations for the protection of the controller. For a specific load, consult the respected electrical specifications to select a suitable fuse.

## INPUT CONNECTION EXAMPLES

### 2.5.1. Thermocouple

The figure below shows the wiring hookup for any thermocouple type. For example, for Type K hookup, connect the yellow wire to the + (+S) Terminal and the red wire to the – (–S) Terminal. **When configuring your controller, select Thermocouple and Thermocouple type in the Input Type menu (see part 3).**



THERMOCOUPLE

Figure 2.5.2 Thermocouple Wiring Hookup

TYPE	Input Connector		Jacket (external insulation)	
	Terminal 1 (-)	Terminal 2 (+)	Extension	Grade
<b>J</b>	Red	White	dark-Brown	Black
<b>K</b>	Red	Yellow	dark-Brown	Yellow
<b>T</b>	Red	Blue	dark-Brown	Blue
<b>E</b>	Red	Purple	dark-Brown	Purple
<b>N</b>	Red	Brown	dark-Brown	Brown
<b>R</b>	Red	Black	-	Green
<b>S</b>	Red	Black	-	Green
<b>B</b>	Red	Black	-	Black

### 2.5.2. Two/Three/Four-Wire RTD


The figures below show the input connections and input connector jumpers required to hookup a 2, 3 or 4-wire RTD.

The **two-wire** connection is the simplest method, but does not compensate for lead-wire temperature change and often requires calibration to cancel lead-wire resistance offset.


The **three-wire** connection works best with RTD leads closely equal in resistance. The controller measures the RTD, plus upper and lower lead drop voltage and then subtracts twice the measured drop in the lower supply current lead producing excellent lead-resistance cancellation for balanced measurements.

The **four-wire** RTD hookup is applicable to unbalanced lead resistance and enables the controller to measure and subtract the lead voltage which produces the best lead-resistance cancellation. When configuring your controller, select RTD type and RTD value in the Input Type Menu (see part 3).


Figure 2.5.3



Two-Wire RTD Hookup




Three-Wire RTD Hookup



Four-Wire RTD Hookup

### 2.5.3. Process Current




The figure shows the wiring hookup for Process Current 0 - 20 mA.

**When configuring your controller, select Process type in the Input Type menu (see part 3).**

Figure 2.5.4 Process Current Wiring Hookup

### 2.5.4. Process Voltage



The figure shows the wiring hookup for Process Voltage 0 - .1 V, 0 - 1 V, or 0 -10 V.

**When configuring your controller, select Process type in the Input Type menu (see part 3).**

Figure 2.5.5 Process Voltage Wiring Hookup

## 3.1 Introduction

---

The Controller has two different modes of operation. The first, *Run Mode*, is used to display values for the process variable, setpoint value and to display or clear peak and valley values. The other mode, *Menu Configuration Mode*, is used to navigate through the menu options and configure the controller.

Part 3 of this manual will explain the *Menu Configuration Mode*. **For your controller to operate properly, the user must first "program" or configure the menu options in the *Menu Configuration Mode*.**

---

### ***Turning Your Controller On for the First Time***

The Controller becomes active as soon as it is connected to a power source. It has no On or Off button. The Controller will at first flash reset on the PV and software version number on the SV display, and then proceed to the *Run Mode*.



OPERATION: *CONFIGURATION MODE*

Button	Function in Configuration Mode
MENU	To enter the Configuration Mode, the user must first press MENU. Use this button to advance/navigate to the next setting. The first menu to appear will be "ID Code", if enabled. The user can navigate through all the top level menus by pressing MENU. Selecting an ID of 0000 will allow you to bypass the ID Menu using the MENU button.
▲/MAX	Press this button to scroll through "flashing" selections. When a numerical value is flashing, this button will increase the active digit from "0" to "9". After "9" the display starts at "0" again. The most significant digit may also show a "-" sign. In the Run Mode MAX causes the display to flash the PEAK - press again to return to the PV value.
▶/MIN	Press this button to go back to a previous Top Level Menu item. Press this button twice to reset the controller to the <i>Run Mode</i> . When a numerical value is flashing, this button will scroll through the digits from left to right digit allowing the user to select the desired digit to modify. In the Run Mode, MIN causes the display to flash the VALLEY - press again to return to the PV value.
ENTER	Press this button to access the submenus from a Top Level Menu item. Also, press this button to store a submenu selection or after entering a value — the display will flash a "stored" message to confirm your selection. To reset flashing PEAK or VALLEY press ENTER. In the Run Mode, press ENTER twice to enable Standby Mode with flashing "Stby".
NOTE:	Except for Setpoints and the Alarms, modifying any settings of the menu configuration will reset the controller prior to resuming Run Mode.

## 3.2 Menu Configuration: *Modifying set points will not reset the controller*




Figure 3.1 Flowchart for ID and Set Point Menus

## OPERATION: CONFIGURATION MODE

### ID Number (if enabled)

**Note**

It is recommended that you put the controller in the Standby Mode for any configuration change other than setpoints & alarms

Display	Action	Response
<b>SEE ID OPTION SUBMENU IN THE BREAK LOOP ALARM SECTION FOR ENABLE/DISABLE ID OPTION</b>		

Press MENU  
Press ENTER

#### ENTERING OR CHANGING YOUR (NON-DEFAULT) ID NUMBER

- 1) Press MENU, if necessary, until " **Id CODE**" prompt appears.
- 2) Display advances to " **Id Cd**", if non-default ID code. If default ID code, the menu will advance to **CH Id** with default value i.e. 0000.

Press MAX & MIN  
  
Press ENTER

**Note**

If the ID code is the default value i.e. 0000, press MENU again and the menu will skip the ID code to Set Point Menu.

- 3) Press MAX to increase digit 0-9. Press MIN to activate next digit (flashing). Continue to use MAX and MIN to enter your 4-digit ID code.
- 4) If the correct ID code is entered, the menu will display **CH Id**, otherwise an error message will be displayed and the controller will return to the Run Mode.

Press MENU  
or  
Press MAX & MIN

- 5) To leave your ID code **Unchanged**, press MENU and advance to "**Set Point**" Menu. To **Change** your ID code use the MAX and MIN buttons to enter a new ID code.

Press ENTER

- 6) Display flashes "**Strd**" message and advances to the next menu "**Set Point**".






**Note**

To prevent unauthorized tampering with the setup parameters, the controller provides protection by requiring the user to enter the ID code before allowing access to subsequent menus. If the ID code entered does not match the ID code stored, the controller responds with an error message and access to subsequent menus will be denied.


**Tip**

Use numbers that are easy for you to remember. If the ID code is forgotten or lost, call customer service with your serial number to reset the default to "0000".

OPERATION: *CONFIGURATION MODE***Set Points (if ID Number Enabled)**

Display	Action	Response
	Press MENU Press ENTER	<b>SETPOINT 1</b> 1) Press MENU, if necessary, until "SEt Pt" prompt appears. 2) Display advances to "SP 1", Setpoint 1.
	Press MAX Press MIN	<b>DISPLAY SHOWS PREVIOUS VALUE. 1ST DIGIT FLASHING.</b> 4) Press MAX to increase digit 0-9. 5) Press MIN to activate next digit (flashing). 6) Continue to use MAX and MIN to enter your 4-digit Setpoint 1 value.
	Press ENTER	7) Display flashes "Strd" message only if a change is made, otherwise press MENU to advance to "SP2", Setpoint 2.
	Press MAX & MIN	<b>SETPOINT 2 : DISPLAY SHOWS PREVIOUS VALUE. 1ST DIGIT FLASHING.</b> 9) Use MAX and MIN buttons to enter your 4-digit Setpoint 2 value.
	Press ENTER	13) Display flashes "Strd" message and advances to "Swapping Setpoints" submenu.




## Setpoints *cont.*

Display	Action	Response																				
		<p><b>OUTPUT REDIRECTION: DISPLAY SHOWS “5 la 1” AND CURRENT SETTING, “5 la 1” OR “5 la2”</b></p> <p>When “5 la 1” is selected, Setpoint 1 (and OUT 1 configuration) direct the control output at label “Output 1” and Setpoint 2 (and OUT 2 configuration) direct the control output at label “Output 2.” When “5 la2” is selected, Setpoint 1 (and OUT 1 configuration) direct the control output at label “Output 2” and Setpoint 2 (and OUT 2 configuration) direct the control at label “Output 1.”</p> <table border="0"> <thead> <tr> <th>Summary</th> <th>Setting</th> <th>Setpoint/Out/LED</th> <th>Output Label</th> </tr> </thead> <tbody> <tr> <td></td> <td>5 la 1</td> <td>1</td> <td>→ 1</td> </tr> <tr> <td></td> <td></td> <td>2</td> <td>→ 2</td> </tr> <tr> <td></td> <td>5 la2</td> <td>1</td> <td>→ 2</td> </tr> <tr> <td></td> <td></td> <td>2</td> <td>→ 1</td> </tr> </tbody> </table>	Summary	Setting	Setpoint/Out/LED	Output Label		5 la 1	1	→ 1			2	→ 2		5 la2	1	→ 2			2	→ 1
Summary	Setting	Setpoint/Out/LED	Output Label																			
	5 la 1	1	→ 1																			
		2	→ 2																			
	5 la2	1	→ 2																			
		2	→ 1																			
	Press MAX	14) Press MAX to select the output option.																				
	Press ENTER	15) Press ENTER to make the selection or MENU to advance to “Input Type”.																				


**Note**

Always put unit in stand-by before redirecting the outputs, and always perform a reset afterward to ensure proper operation. With Analog Proportional output option, the following issues need to be considered when redirecting the output: 1) Current (4-20 mA) output is disabled; 2) %Hi/Lo and SELF setting is moved to Out 2 configuration menu; 3) Control Type and Cycle Time appear in Out 1 and is associated with time proportional control at Output 2; 4) Control Type and Cycle Time setting in Out 2 is disregarded by Analog Proportional output.

OPERATION: *CONFIGURATION MODE***Set Points (if ID Number Disabled - default)**

Display	Action	Response
	Press MENU (1 time) Press MAX Press MIN  Press ENTER	<p>With ID number disabled and in Run Mode, pressing MENU one time advances the controller to Setpoint 1 setting directly.</p> <p><b>SET POINT 1</b></p> <ol style="list-style-type: none"> <li>1) Press MENU once from Run Mode.</li> <li>2) Display flashes the first digit of Setpoint 1.</li> <li>3) Press MAX to set the digit, 0-9.</li> <li>4) Press MIN to activate the next digit (flashing).</li> <li>5) Repeat step 3 and 4 until all digits are set.</li> <li>6) Controller stores new setting and returns to Run Mode.</li> </ol>
	Press MENU (2 times)	<p><b>SET POINT 2</b></p> <ol style="list-style-type: none"> <li>1) Press MENU twice from Run Mode.</li> <li>2) Display flashes the first digit of Setpoint 2.</li> <li>3) Follow step 3 to 6 of Setpoint 1 to complete the setting.</li> </ol>
	Press MENU (3 times) Press MAX Press ENTER	<p><b>OUTPUT REDIRECTION</b></p> <ol style="list-style-type: none"> <li>1) Press MENU 3 times from Run Mode.</li> <li>2) Display flashes “<b>5 to 1</b>” in the SV window. (See previous page for more details.)</li> <li>3) Press MAX to select the output option.</li> <li>4) Press ENTER to make the selection or MENU to advance to “Input Type”.</li> </ol>

# OPERATION: CONFIGURATION MODE



**Figure 3.2 Flowchart for Input Type**

## Input Type (Thermocouple)

Display	Action	Response
	Press MENU Press ENTER	<b>ENTER INPUT TYPE MENU:</b> 1) Press MENU, if necessary, until " <b>InPt tYPE</b> " prompt appears. 2) Display flashes " <b>rtD</b> ", " <b>tC</b> ", or " <b>Proc</b> " (RTD, Thermocouple, Process), if the displayed input type is <b>tC</b> , press MENU to skip to step 5 ( <b>tC</b> stops flashing).
	Press MAX Press ENTER Press ENTER	<b>THERMOCOUPLE SUBMENU:</b> 3) Press MAX to scroll to " <b>tC</b> " (flashing). 4) Display flashes "stored" message and " <b>tC</b> " stops flashing. 5) Display flashes previous thermocouple type selection. ie. " <b>J</b> " (see below for types).
	Press MAX Press ENTER	6) Scroll through the available thermocouple types to the selection of your choice. 7) Display flashes " <b>Strd</b> " message and advances to the next menu Reading Configuration.




**Note**

Use the Input Type (Thermocouple) (RTD) or (Process) and verify your Dip Switch Setting (see section 2.4) and your Electrical Installation (see section 2.5). See the following pages for (RTD) and (Process) menus.

**Thermocouple Types:** ( J, K, T, E, N, DIN J, R, S, B, C)  
**Display:** J CA t E n dnJ r S b C



## Input Type (RTD)

Display	Action	Response
	Press MENU Press ENTER	<b>ENTER INPUT TYPE MENU:</b> 1) Press MENU, if necessary, until " <b>InPt tYPE</b> " prompt appears. 2) Display flashes " <b>rtd</b> ", " <b>tc</b> ", or " <b>Proc</b> " (RTD, Thermocouple, Process), if the displayed input type is <b>rtd</b> , press MENU to skip to step 5 ( <b>rtd</b> stops flashing).
	Press MAX Press ENTER Press ENTER	<b>RTD SUBMENU:</b> 3) Press MAX to scroll to " <b>rtd</b> " (flashing). 4) Display flashes "stored" message and " <b>rtd</b> " stops flashing 5) Display flashes previous RTD type selection ie. 392.2. (See below for RTD types.)
	Press MAX Press ENTER	6) Scroll through the available RTD types to the selection of your choice: 7) Display flashes " <b>Stcrd</b> " message and advances to " <b>rtd uRLU</b> ".




**RTD Types:** 385, 392, Two, Three and Four-wire

**Display:** 392.2 392.3 392.4 385.2 385.3 385.4

**Note** 

Last digit indicates: 2, 3 or 4-wire input.

OPERATION: *CONFIGURATION MODE***Input Type (RTD Value)**




Display	Action	Response
	Press ENTER	<b>RTD VALUE SUBMENU:</b> 8) Press ENTER at " <i>rtd uALU</i> " prompt to enter your RTD Value. Display flashes previous RTD value selection ie. <i>100_</i> (see below for RTD value selections)
	Press MAX	9) Scroll through the available RTD Values to the selection of your choice:
	Press ENTER	10) Display flashes "stored" message and advances to "Reading Configuration".

**RTD Values:** All RTD's may be:  
100 ohm    500 ohm    1000 ohm

**Display:**        *100\_*    *500\_*    *1000*

## OPERATION: CONFIGURATION MODE

### Input Type (Process)

Display	Action	Response
	Press MENU Press ENTER	<b>ENTER INPUT TYPE MENU:</b> 1) Press MENU, if necessary, until " <b>InPt TYPE</b> " prompt appears. 2) Display flashes " <b>rtd</b> ", " <b>tc</b> ", or " <b>Proc</b> " (RTD, Thermocouple, Process), if the displayed input type is Process, press MENU to skip to step 5 ( <b>Proc</b> stops flashing).
	Press MAX Press ENTER Press ENTER	<b>PROCESS SUBMENU:</b> 3) Press MAX to scroll to " <b>Proc</b> " (flashing). 4) Display flashes "stored" message and " <b>Proc</b> " stops flashing. 5) Display flashes previous Process type selection. ie. " <b>0-10</b> " (See below for types.)
	Press MAX Press ENTER	6) Scroll through the available Process types to the selection of your choice. 7) Display flashes "stored" message and advances to the next menu "Reading Configuration".

**Note**

Use the Input Type (Thermocouple) (RTD) or (Process) and verify your Dip Switch Setting (see section 2.4) and your Electrical Installation (see section 2.5). See the previous pages for (RTD) and (Process) menus.

<b>Process Types:</b>	100mV	1V	10V	0-20 mA
<b>Display:</b>	0-01	0-10	0-10	0-20
Natural Gain	100 cts/mv	10 cts/1mV	1 ct/mV	500 cts/mA
Max Display	9999 @100 mv	9999 @ 1V	9999 @ 10V	9999 @ 20 mA

**Note**

For 4-20 mA Input select 0-20 mA and adjust the Input Scale & Offset accordingly. To adjust 4-20 mA input. (See example under INPUT Scale & Offset.)

# OPERATION: CONFIGURATION MODE









Figure 3.3 Flowchart for Reading Configuration

## Reading Configuration

Display	Action	Response
	Press MENU Press ENTER	<ol style="list-style-type: none"> <li>1) Press MENU, if necessary, until "Reading Configuration" prompt appears.</li> <li>2) Display advances to "<b>dEC Pt</b>" (Decimal Point).</li> </ol>
<b>DECIMAL POINT SUBMENU:</b>		
	Press ENTER	3) Display flashes previous selection for decimal location.
	Press MAX Press ENTER	<ol style="list-style-type: none"> <li>4) Scroll though the available selections and choose decimal location: <b>FFFF</b>. or <b>FFF.F</b> (also <b>F.FFF</b> and <b>FF.FF</b> — if "Process" type was selected in the "<b>INPut tYPE</b>" menu).</li> <li>5) Display flashes "<b>Strd</b>" message and advances to "Temperature Unit".</li> </ol>
<div style="display: flex; align-items: center;"> <div style="background-color: black; color: white; padding: 2px 5px; font-weight: bold; font-size: small;">Note</div> <div style="margin-left: 10px;">Decimal point for Process input type is passive.</div> </div>		
<b>TEMPERATURE UNIT SUBMENU:</b>		
	Press ENTER	6) Display flashes previous Temperature Unit selection.
	Press MAX Press ENTER	<ol style="list-style-type: none"> <li>7) Scroll though the available selections to the temperature unit of your choice: °F or °C.</li> <li>8) Display flashes "<b>Strd</b>" message and advances to "Filter Constant".</li> </ol>








## Reading Configuration *cont.*

Display	Action	Response
	Press ENTER Press MAX	<b>FILTER CONSTANT SUBMENU:</b> 9) Display flashes previous selection for filter constant. 10) Scroll though the available selections: <b>0001, 0002, 0004, 0008, 0016, 0032, 0064, 0128. - Default is 0004</b>
	Press ENTER	11) Display flashes "stored" message only if change was made.
		<b>Note</b> For PID control select filter value 0001-0004. A filter value of 2 is approximately equal to 1 sec. RC low pass time constant.
		<i>If Process was selected in the "Input Type" menu the display will advance to "Input SC &amp; OFF", otherwise the display advances to the "Alarm 1" menu.</i>

**Note** The **Filter Constant** submenu allows the user to specify the number of readings stored in the digital averaging filter.

## OPERATION: CONFIGURATION MODE

## Reading Configuration cont. (If process was selected)

Display	Action	Response
<b>INPUT SCALE &amp; OFFSET SUBMENU:</b>		
	Press ENTER	12) Press enter at the "InPt SCDF" prompt. Display flashes 1st digit in submenu "In 1"
	Press MAX & MIN	13) Use MAX and MIN buttons to enter "In 1" value. The "In 1" value = min. input value * the natural gain. Example: 4(mA) x 500 = 2000
	Press ENTER	14) Display advances to "rd 1" submenu.
	Press MAX & MIN	15) Use MAX and MIN buttons to enter "rd 1" value. This value responds to "In 1" in terms of some meaningful engineering units
	Press ENTER	16) Display advances to "In 2" submenu. The "In 2" value = max. input value * the natural gain. Example: 20(mA) x 500 = 10000 (9999)
	Press MAX & MIN	17) Use MAX and MIN buttons to enter "In 2" value.
	Press ENTER	18) Display advances to "rd 2" submenu.
	Press MAX & MIN	19) Use MAX and MIN buttons to enter "rd 2" value.
	Press ENTER	20) Display flashes "stored" message and advances to "ALAR 1" menu.
	<b>Note</b>	<b>This submenu allows the user to scale the meter when in Process Mode and the above display value is an example for 4-20 mA input (4 to 20 mA = 0000 to 0100%).</b>

# OPERATION: CONFIGURATION MODE

## Modifying Alarm settings will not reset the controller







Figure 3.4 Flowchart for Alarm 1 and Alarm 2



## Alarm 1




Display	Action	Response
	Press MENU Press ENTER	<ol style="list-style-type: none"> <li>1) Press MENU, if necessary, until "<b>ALAr 1</b>" prompt appears.</li> <li>2) Display advances to "<b>ALAr.1 Enbl</b>" or "<b>dSbl</b>" submenu.</li> </ol>
	Press MAX Press ENTER	<p><b>ALARM 1 ENABLE/DISABLE SUBMENU:</b></p> <ol style="list-style-type: none"> <li>3) Display flashes previous selection. Press MAX until "<b>Enbl</b>" displays to use Alarm 1.</li> <li>4) Display flashes "<b>Strd</b>" message only if it was changed, otherwise press MENU to advance to "Control Type" submenu.</li> </ol>
	Press MAX Press ENTER	<p><b>CONTROL TYPE SUBMENU:</b></p> <ol style="list-style-type: none"> <li>5) Display flashes previous selection. Press MAX to "<b>Abs0</b>" or "<b>dEu</b>"</li> <li>6) Display flashes "<b>Strd</b>" message only if it was changed, otherwise press MENU to advance to "Alarm 1 Latch" submenu.</li> </ol>

**Note** 

**Absolute** Mode allows Alarm 1 to function independently from Setpoint 1. If the process being monitored does not change often, then "Absolute" Mode is recommended.

**Deviation** Mode allows changes to Setpoint 1 to be made automatically to Alarm 1. Deviation Mode is typically the ideal mode if the process temperature changes often. In Deviation Mode, set Alarm 1 a certain number of degrees or counts away from Setpoint 1 — this relation remains fixed even if Setpoint 1 is changed.

OPERATION: *CONFIGURATION MODE***Alarm 1 cont.**

Display	Action	Response
	Press MAX Press ENTER	<b>ALARM LATCHED OR UNLATCHED SUBMENU:</b> 7) Display flashes previous selection. Press MAX to <b>Latched</b> or <b>Unlatched</b> . 8) Display flashes " <b>Strd</b> " message and advances to "Contact Closure" submenu.
	Press MAX Press ENTER	<b>CONTACT CLOSURE SUBMENU:</b> 9) Display flashes previous selection. Press MAX to <b>Normally Closed (nc)</b> or <b>Normally Open (no)</b> . 10) Display flashes " <b>Strd</b> " message only if it was changed, otherwise press MENU to advance to "Alarm 1 Setup" submenu.
	Press MAX Press ENTER	<b>ALARM 1 SETUP SUBMENU:</b> 13) Display flashes previous selection. Press MAX to scroll through the available selections: <b>Above</b> , <b>Below</b> , <b>Hi/Low</b> and <b>Band</b> (Band is active if "Deviation" was selected). 14) Display flashes " <b>Strd</b> " message only if it was changed, otherwise press MENU to advance to "Alarm 1 Low Value" submenu.

**Above:** Alarm 1 condition triggered when the process variable is greater than the Alarm **Hi Value**. (Lo value ignored)

**Below:** Alarm 1 condition triggered when the process variable is less than the Alarm **Low Value**. (Hi value ignored)




**Hi/Low:** Alarm 1 condition triggered when the process variable is less than the Alarm **Low Value** or above the **Hi Value**.

**Band:** Alarm 1 condition triggered when the process variable is above or below the "Band" set around Setpoint 1. Band equals **Hi Value** (Lo Value ignored). A "Band" is set around the Setpoint 1 by the controller only in the "Deviation" Mode.

## Alarm 1 cont.

Display	Action	Response
	Press MAX	<p><b>ALARMS ENABLE/DISABLE AT POWER ON:</b></p> <p>11) Display flashes previous selection. Press MAX to enable or disable.</p>
	Press ENTER	<p><b>Note</b> ☞ If the alarm is enabled at Power On, the alarm will be active right after reset. If the alarm is disabled at Power On, the alarm will become enabled when the process value enters the non alarm area. The alarm is not active while the Process value is approaching Setpoint 1.</p> <p>12) Display flashes "Stored" message only if it was changed, otherwise press MENU to advance to the "Alarm 1 Low Value" submenu.</p>
	Press MAX & MIN	<p><b>ALARM 1 LOW VALUE SUBMENU:</b></p> <p>15) Display flashes 1st digit of previous value. Use MAX and MIN to enter new value.</p>
	Press ENTER	<p>16) Display flashes "<b>Strd</b>" message, only if it was changed, otherwise press MENU to advance to "Alarm 1 HI Value" submenu.</p>
	Press MAX & MIN	<p><b>ALARM 1 HI VALUE SUBMENU:</b></p> <p>17) Display flashes 1st digit of previous value. Use MAX and MIN to enter new value.</p>
	Press ENTER	<p>18) Display flashes "<b>Strd</b>" message only if it was changed, otherwise press MENU to advances to "Alarm 2" submenu.</p>
<p><b>Note</b> ☞</p>	<p><b>Latched Mode:</b> Relay remains "latched" until reset. To reset a latched alarm, put unit into "Stand-by" Mode by pressing the ENTER button twice. Then, enter back into Run Mode by pressing the ENTER button a third time and alarm will be de-energized.</p> <p><b>Unlatched Mode:</b> Relay remains latched only as long as the alarm condition is true.</p> <p><b>Normally Closed:</b> "Fail Safe" Mode, relay is energized under "normal" conditions and becomes de-energized during alarm or power failure.</p> <p><b>Normally Open:</b> If this feature is selected, then the relay is "energized" only when an alarm condition occurs.</p>	


OPERATION: *CONFIGURATION MODE***Alarm 2**

Display	Action	Response
	Press MENU Press ENTER	<ol style="list-style-type: none"> <li>1) Press MENU, if necessary, until "<b>ALAr 2</b>" display appears.</li> <li>2) Display advances to "Alarm 2 Enable/Disable" submenu.</li> </ol>
	Press MENU	<p><b>IF ALARM 2 IS NOT INSTALLED, THE CONTROLLER WILL SHOW "NOT INSTALLED"</b></p> <p>Press MENU, if you receive the "not installed" message and advance to the "Loop Break" menu.</p>
	Press MAX Press ENTER	<p><b>ALARM 2 ENABLE/DISABLE SUBMENU:</b></p> <ol style="list-style-type: none"> <li>3) Display flashes previous selection. Press MAX until "<b>Enbl</b>" displays to use Alarm 2.</li> <li>4) Display flashes "<b>Strd</b>" message only if it was changed, otherwise press MENU to advance to "Control Type" submenu.</li> </ol>

**Note**



The remaining Alarm 2 is identical to Alarm 1 i.e. previous two pages.

# OPERATION: *CONFIGURATION MODE*





**Figure 3.5 Flowchart for Loop Break**


OPERATION: *CONFIGURATION MODE***Loop Break Alarm**


Display	Action	Response
	Press MENU Press ENTER	<ol style="list-style-type: none"> <li>1) Press MENU, if necessary, until the "Loop Break" prompt appears.</li> <li>2) Display advances to "Loop Break Enable/Disable" submenu.</li> </ol>
	Press ENTER Press MAX Press ENTER	<p><b>LOOP BREAK ENABLE/DISABLE SUBMENU:</b></p> <ol style="list-style-type: none"> <li>3) Display flashes "<b>EnbL</b>" or "<b>d5bL</b>".</li> <li>4) Scroll through the available selections: <b>Enable (EnbL)</b> or <b>Disable (d5bL)</b>.</li> <li>5) Display flashes "<b>Strd</b>" message and advances to "Loop Value" menu.</li> </ol>

**Note** **Loop Break** is an additional safety feature intended to monitor the rate of change of the process value, while approaching the SPI. It is strictly intended as an additional warning system, therefore its use is entirely optional. An active Loop Break will cause the setpoint digits to blink in a rotating pattern. If the process value reaches the setpoint the blinking will stop and **LoOP brAL** is completed successfully, otherwise **LoOP brAL** will flash and will activate **ALr l**.

## Loop Break Alarm cont.

Display	Action	Response
	Press ENTER Press MAX & MIN Press ENTER	<b>LOOP BREAK ALARM VALUE SUBMENU:</b> 6) Display flashes 1st digit of previous loop value. 7) Press MAX and MIN buttons to enter a new "Loop Value". 8) Display flashes " <b>Strd</b> " message and advances to "CJ Temperature Adjust" Menu.
	Press ENTER Press MAX & MIN Press ENTER	<b>TEMPERATURE ADJUST SUBMENU:</b> 9) Display flashes 1st digit of previous temperature adjust value. 10) Press MAX and MIN buttons to enter a new "Temperature Adjust" value. 11) Display flashes " <b>Strd</b> " message and advances to "ID Option" submenu.


**Note**  **Loop Break Alarm Value** allows the user to determine the time interval in MM:SS (from zero to 99 minutes and 59 seconds) that the process value changes 10 counts or if the input type is either RTD or Thermocouple, the value would be 4°Fahrenheit or 2°Celsius. At the specified time interval, if the process value change is less than the stated rate flashing, "**LbAL**" will be displayed, the output "**I**" will be de-energized, and Alarm 1 energized. Loop Break Alarm will be disabled when the process value (PV) enters the control band.

**Tip**  Display Offset Adjust allows the user to fine tune a minor error of the transducer, however some applications may require a large offset adjust. (Displayed Process Value = Measured Process Value ± **tAdJ**). **tAdJ** is adjustable between -1999 to 9999.

---

## Loop Break Alarm *cont.*

---

Display	Action	Response
	Press MAX Press ENTER	<b>ID CODE OPTION SUBMENU</b> 12) Display flashes current status of ID Option, enabled or disabled. 13) Press MAX button to select between <b>Enable</b> and <b>Disable</b> . 14) Display flashes “ <b>5trd</b> ” and advances to “Output 1.”

**Note**

With ID Code Option disabled, the ID Number submenu is hidden. Refer to the appropriate setpoints section for setting differences.



# OPERATION: CONFIGURATION MODE












Figure 3.6 Flowchart for Output 1

OPERATION: *CONFIGURATION MODE***Output 1**

Display	Action	Response
	Press MENU Press ENTER	<ol style="list-style-type: none"> <li>1) Press MENU, if necessary, until the "out 1" prompt appears.</li> <li>2) Display advances to "Self" submenu.</li> </ol>
	Press MAX Press ENTER	<p><b>SELF SUBMENU</b></p> <p>The Self Option allows the output of the controller to be controlled manually from the front panel.</p> <ol style="list-style-type: none"> <li>3) Display flashes the current setting of Self, enabled or disabled.</li> <li>4) Press the MAX button to select between Enable and Disable.</li> <li>5) If Self enable was selected, Output 1 setting is completed and the display advances to the next menu.</li> </ol>
		<p>The output is now under the direct control of the operator and can be adjusted in the run mode, by pressing the MAX and MIN buttons. The control value (0 - 99), now displayed in the SV window indicate, approximately in percent, the output. For example, a setting of 0050 of an analog output of 0~10 Vdc would produce roughly 5 Vdc at the output. Also, to insure smooth transition when switching to self mode, the proportional control output is left in its last value, when Self Mode is activated for the first time.</p>
		<ol style="list-style-type: none"> <li>6) Display advances to the "Minimum/Percent Low" submenu, if Self is disabled.</li> </ol>
		<p><b>MINIMUM/PERCENT LOW SUBMENU</b></p> <p>Specify in percent, the minimum value (0000) for control output. If the output is analog, then the minimum voltage or current, in percent, is specified. If the output is time proportional, then the minimum duty-cycle, in percent, is specified.</p>
	Press MIN & MAX Press ENTER	<ol style="list-style-type: none"> <li>7) Display shows "0%LO", and flashes the 10s digit of the current "Percent Low" setting.</li> <li>8) Use MAX &amp; MIN buttons to enter a new value for "Percent Low".</li> <li>9) Press ENTER to store the current setting and to advance to Maximum/Percent High.</li> </ol>

## Output 1 cont.

Display	Action	Response
	Press MIN & MAX Press ENTER	<p><b>MAXIMUM/PERCENT HIGH SUBMENU</b> Specify in percent, the maximum value (0099) for control output. If the output is analog, then the maximum voltage or current, in percent, is specified. If the output is time proportional, then the maximum duty-cycle, in percent, is specified.</p> <p>10) Display shows "00HI" and flashes the 10s digit of the current Percent Low setting. 11) Use MAX &amp; MIN buttons to enter a new value for Percent Low. 12) Press ENTER to store the current setting and to advance to *Control Type submenu.</p>
<p><b>Example:</b> On an analog output of 0~10 Vdc, a setting of %LO = 10 and %HI = 90, cause the minimum on the control output to be 1 V and the maximum on the control output to be 9 V. The same setting on a time proportional output, will cause 10% duty cycle for the minimum control output and 90% duty cycle for the maximum control output. To disable %LO/HI, set LO to 00 and HI to 99. If %LO/HI is at other values than the default (%LO = 00, %HI = 99), "Soak" is disabled.</p>		
	Press ENTER Press MAX	<p><b>*CONTROL TYPE SUBMENU: (Relay, SSR or Pulse Option)</b></p> <p>13) Display flashes "On.Off" or "PID". 14) Scroll through the available selections: <b>ON/OFF</b> or <b>PID</b>.</p>
	Press ENTER	15) Display flashes "Strd" message and advances to "Action Type" submenu.
	<p>The <b>ON/OFF</b> control is a coarse way of controlling the process. The "Dead Band" improves the cycling associated with the On/Off control. The <b>PID</b> control is best for processes where the setpoint is continuously changing and/or a tight control of the process variable is required. PID control requires tuning and adjustment of the "Proportional", "Integral or Reset" and "Derivative or Rate" terms by a trial-and-error method. The Controller provides an "Auto Tuning" feature making the tuning process automatic, possibly optimum.</p>	

### Output 1 cont.

Display	Action	Response
---------	--------	----------

\*If Current/Voltage is your analog control output 1, this menu i.e. **ctrl** type will not appear, instead 4-20/Curr will be displayed. Select "**Enbl**" for a 4-20 mA (2-10 V) output or "**d5bl**" for a 0-20 mA (0-10 V) output. If 4-20 mA is enabled, %HI/LO setting will have no effect.

**Note**

Both Current and Voltage control outputs are active simultaneously.

Press ENTER

#### ACTION TYPE SUBMENU:

16) Display flashes "**drct**" or "**rvrs**".

Press MAX

17) Scroll through the available selections: **Direct** or **Reverse**.

Press ENTER





18) Display flashes "**Strd**" message and advances to "Auto PID" submenu.

If "**ON/OFF**" was selected in the Control Type, the display skips to the "**Dead Band**" submenu.





**Note**

The error that results from the measurement of the process variable may be positive or negative since it may be greater or smaller than the set point. If a positive error should cause the controller output to increase (i.e. cooling), it would be called **Direct Acting**. If a negative error should cause the output to increase (i.e. heating), it would be called **Reverse Acting**.

OPERATION: *CONFIGURATION MODE***Output 1 cont.**

Display	Action	Response
	Press ENTER Press MAX	<b>AUTO PID SUBMENU:</b> 19) Display flashes " <b>EnbL</b> " or " <b>d5bL</b> ". 20) Scroll through the available selections: Enable or Disable.
		If " <b>Enabled</b> ", the controller can determine, by enabling Start PID, the optimum values for the three adjustments — Proportional, Reset and Rate corresponding to P, I, and D. These values may be changed once the auto tuning is complete. If " <b>Disabled</b> " is selected, the user will manually enter these three adjustment values. If you want the controller to do the auto <b>P Id</b> and the <b>P, P I</b> or <b>P Id</b> , first select auto disable and enter 0000 for the unwanted parameter. e.g. for <b>P I</b> enter 0000 for the rate.
	Press ENTER	21) Display flashes "stored" message and advances to "Adaptive Control" submenu.
	Press ENTER Press MAX	<b>*ADAPTIVE CONTROL SUBMENU: * (NOT INSTALLED)</b> 22) Display flashes " <b>EnbL</b> " or " <b>d5bL</b> ". 23) Scroll through the available selections: <b>Enable</b> or <b>Disable</b> .
		If " <b>Enabled</b> ", the Adaptive Tuning dynamically changes and updates the P, I, and D parameters for optimum control. The adaptive tuning is useful when the load continuously changes thereby requiring new values for <b>P, I, and d</b> .
	Press ENTER	24) Display flashes "stored" message and advances to "Anti Integral" submenu.




### Output 1 cont.

Display	Action	Response
	Press ENTER Press MAX	<b>ANTI INTEGRAL SUBMENU:</b> 25) Display flashes " <b>Enbl</b> " or " <b>d5bl</b> ". 26) Scroll through the available selections: <b>Enable</b> or <b>Disable</b> .
	Press ENTER	If " <b>Enabled</b> ", this feature allows the error term outside the proportional band to be calculated and accumulated for integration. This may be an important feature in applications where fast response time is desirable. 27) Display flashes "stored" message and advances to "Proportional Band" submenu if Auto PID was disabled, otherwise it will go to " <b>Start PID</b> ".
	Press ENTER Press MAX	<b>START AUTO TUNE PID:</b> 28) Display flashes " <b>Enbl</b> " or " <b>d5bl</b> ". 29) Scroll through the available selections: <b>Enable</b> or <b>Disable</b> .
	Press ENTER	If " <b>Enabled</b> ", the controller is ready to calculate P, PI or PID parameters. The setpoints must be at least 20°F or 11°C above the (PV) Process Value in order to perform autotune, otherwise an error message will be displayed. 30) Display flashes " <b>Strd</b> " message and advances to the "Cycle Time" submenu.



**Note**

To start Auto Tune PID select PID, enable Auto PID and enable Start PID. Sometimes Auto PID parameter needs fine tuning i.e. for each 5°F over shoot increase the Proportional Band (PB) by 15% and for each ±1°F fluctuation at the Setpoint (SP) increase reset by 20%. **Once started, display shows "Rtun" with the letters blinking in the rotating pattern. Do not perform any operations or settings before first stopping Auto Tune. Any alarms or other output is disabled during Auto Tune.**

OPERATION: *CONFIGURATION MODE***Output 1 cont.**

Display	Action	Response
	Press ENTER Press MAX & MIN Press ENTER	<p>If "AUTO TUNE PID" was "DISABLED", the display will show the following three submenus so the user may manually enter values for Proportional, Reset and Rate terms corresponding to P, I, and D. It also can be used for auto PID for disabling unwanted parameters e. g. PI, enter 0000 for rate:</p> <p><b>PROPORTIONAL BAND SUBMENU:</b></p> <p>28) Display flashes 1st digit of the previous P "Proportional Band" value. 29) Press MAX and MIN buttons to enter a new "Proportional Band" value. 30) Display flashes "<b>Strd</b>" message and advances to "Reset Setup" submenu. <b>NOTE:</b> Proportional band is in degrees of temperature or counts of process.</p>
	Press ENTER Press MAX & MIN Press ENTER	<p><b>RESET SETUP SUBMENU:</b></p> <p>31) Display flashes 1st digit of the previous I "Reset" value. 32) Press MAX and MIN buttons to enter a new "Reset" value. 33) Display flashes "<b>Strd</b>" message and advances to "Rate Setup" menu. <b>NOTE:</b> Reset unit is in seconds 0-3999.</p>
	Press ENTER Press MAX & MIN Press ENTER	<p><b>RATE SETUP SUBMENU:</b></p> <p>34) Display flashes 1st digit of previous D "Rate" value. 35) Press MAX and MIN buttons to enter a new "Rate" value. 36) Display flashes "<b>Strd</b>" message and advances to the "Cycle Time" submenu for RTD and Thermocouple types. <b>If the Output 1 is analog option the display skips to "Damping Factor"</b>. <b>NOTE:</b> Rate unit is in seconds 000.0-399.9.</p>

OPERATION: *CONFIGURATION MODE***Output 1 cont.**



Display	Action	Response
	Press ENTER	<b>CYCLE TIME SUBMENU:</b> 37) Display flashes 1st digit of the previous "Cycle Time" value.
	Press MAX & MIN	38) Press MAX and MIN buttons to enter a new "Cycle Time" value. (1 to 199 seconds).
	Press ENTER	39) Display flashes "stored" message and advances to "Damping Factor" submenu.

**Note**

A Cycle Time selected between 1 and 199 seconds determines the total On/Off time of each proportional cycle. For example, a 15 second Cycle Time means that every 15 seconds the output will turn on for part or all of the cycle. For Relay control outputs, do not select a cycle time of less than 7 seconds or the relays life time will be shortened. For a Cycle Time of less than 7 seconds select SSR or DC pulse. Use an external SSR with the DC pulse option for higher currents (higher than 1 Amp).





## Output 1 cont.

Display	Action	Response
	Press ENTER	<b>DAMPING FACTOR SUBMENU:</b> 40) Display flashes the previous "Damping Factor" selection.
	Press MAX	41) Scroll through the available selections: <b>0000, 0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008 - Default is 0003.</b>
	Press ENTER	42) Display flashes " <b>Strd</b> " message and advances to the "Output 2" menu.

**Note**

**Damping Factor** is a measure of speed, overshoot, and undershoot in which the process variable responds to the output changes of the controller, which were used during the Auto Tune. This value is typically set to the ratio of Rate to Reset. This Default value is (0003). For fast response time, this value should be decreased while for slow response time it should be increased.

OPERATION: *CONFIGURATION MODE***Output 1 cont.**

Display	Action	Response
		The "Dead Band" submenu will only appear if the "On/Off" was selected from the "Control Type" menu.
	Press ENTER	<b>DEADBAND SUBMENU:</b> 43) Display flashes 1st digit of the previous "Dead Band" value.
	Press MAX & MIN Press ENTER	44) Press MAX and MIN buttons to enter a new "Dead Band" value 45) Display flashes " <b>Strd</b> " message and advances to the "Output 2" menu.
		<b>Note</b> ☞ Dead Band units are the degree of temperature or counts of process.

**Note** ☞

The Dead Band or neutral zone is the number of degrees or counts (if input type is process) around the setpoint which the process variable must pass above or below the setpoint, before the output changes state.

# OPERATION: CONFIGURATION MODE








Figure 3.7 Flowchart for Output 2



OPERATION: *CONFIGURATION MODE***Output 2**

Display	Action	Response
	Press MENU Press ENTER	<ol style="list-style-type: none"> <li>1) Press MENU, if necessary, until the "<b>out 2</b>" prompt appears.</li> <li>2) Display advances to "Control Type" submenu.</li> </ol>
	Press MENU	<p><b>IF OUTPUT 2 IS NOT INSTALLED, THE CONTROLLER WILL SHOW "NOT INSTALLED"</b></p> <p>Press MENU, if the "not installed" message is displayed, advance to the "Ramp &amp; Soak" submenu.</p>
	Press ENTER Press MAX	<p><b>CONTROL TYPE SUBMENU:</b></p> <ol style="list-style-type: none"> <li>3) Display flashes "<b>On.OFF</b>" or "<b>P Id</b>".</li> <li>4) Scroll through the available selections: <b>On.OFF</b> or <b>P Id</b>.</li> </ol>
	Press ENTER	<ol style="list-style-type: none"> <li>5) Display flashes "<b>Strd</b>" message and advances to "Action Type" submenu.</li> </ol>

**Note**

The **ON/OFF** control is a coarse way of controlling the process. The "Dead Band" improves the cycling associated with the On/Off control. The **PID** control is best for processes where the set point is continuously changing and/or tight control of the process variable is required.

## Output 2 cont.






Display	Action	Response
	Press ENTER	<b>ACTION TYPE SUBMENU:</b> 6) Display flashes " <b>drct</b> " or " <b>rUr5</b> ". 7) Scroll through the available selections: <b>Direct</b> or <b>Reverse</b> . 8) Display flashes " <b>Strd</b> " message and advances to "Auto PID" submenu.  <b>If "ON/OFF" was selected in the Control Type, the display skips to the "Deadband" submenu.</b>
	Press MAX	
	Press ENTER	

**Note**



The error that results from the measurement of the process variable may be positive or negative since it may be greater or smaller than the set point. If a positive error should cause the controller output to increase (i.e. cooling), it would be called **Direct Acting**. If a negative error should cause the output to increase (i.e. heating), it would be called **Reverse Acting**.

## OPERATION: CONFIGURATION MODE

## Output 2 cont.

Display	Action	Response
	Press ENTER Press MAX	<b>AUTO PID SUBMENU:</b> 9) Display flashes "Enbl" or "d5bl". 10) Scroll through the available selections: <b>Enable</b> or <b>Disable</b> .  If "Enabled", the PID parameter of Output 1 will be copied to Output 2.
	Press ENTER	11) Display flashes "Strd" message and advances to the next submenu —  <b>If "Auto PID" was "Enabled", the display skips to the "Cycle Time" submenu.</b> <b>If "Auto PID" was "Disabled", the display will show the "Proportional Band" submenu allowing the user to manually enter the Proportional Band value.</b>
		<b>Note</b>  <i>The Reset and Rate value are the same as Output 1.</i>
	Press ENTER Press MAX & MIN Press ENTER	<b>PROPORTIONAL BAND SUBMENU:</b> 12) Display flashes 1st digit of the previous "Proportional Band" value. 13) Press MAX and MIN buttons to enter a new "Proportional Band" value. 14) Display flashes "Strd" message and advances to the "Cycle Time" submenu.
		<b>Note</b>  <i>Refer to Proportional Band, submenu of Output 1 Menu.</i>



**Output 2 cont.**

Display	Action	Response
	Press ENTER	<b>CYCLE TIME SUBMENU:</b> 15) Display flashes 1st digit of the previous "Cycle Time" value.
	Press MAX & MIN	16) Press MAX and MIN buttons to enter a new "Cycle Time" value. (1 to 199 seconds).
	Press ENTER	17) Display flashes "stored" message and advances to "Ramp & Soak" Menu.

**Note**

A Cycle Time selected between 1 to 199 seconds indicates the total On/Off time of each proportional cycle. For example, a 15 second Cycle Time means that every 15 seconds the output will turn on for part or all of the cycle. For Relay control outputs, do not select a cycle time of less than 7 seconds or the relays life time will be shortened. For a cycle time of less than 7 seconds select SSR or DC pulse. Use an external SSR with the DC pulse option for higher current (higher than 1 Amp).

## Output 2 cont.


Display	Action	Response
		The "Dead Band" submenu will only appear if the "On/Off" was selected from the "Control Type" menu.
	Press ENTER	<b>DEAD BAND SUBMENU:</b> 18) Display flashes 1st digit of the previous "Dead Band" value.
	Press MAX & MIN Press ENTER	19) Press MAX and MIN buttons to enter a new "Dead Band" value. 20) Display flashes "stored" message and advances to the "Ramp Value" menu.
		<b>Note</b> Refer to Dead Band submenu of Output 1 Menu.

**Note**

The Dead Band is the number of degrees or counts around the setpoint which the process variable must pass through before the output changes state.






# OPERATION: *CONFIGURATION MODE*



**Figure 3.8** *Flowchart for Ramp & Soak*

## Ramp & Soak



Display	Action	Response
	Press MENU Press ENTER	<ol style="list-style-type: none"> <li>1) Press MENU, if necessary, until the "<b>rANP SoAc</b>" prompt appears.</li> <li>2) Display advances to "Ramp Enable/Disable" submenu.</li> </ol>
	Press ENTER Press MAX Press ENTER	<p><b>RAMP ENABLE/DISABLE SUBMENU:</b></p> <ol style="list-style-type: none"> <li>3) Display flashes "<b>Enbl</b>" or "<b>d5bl</b>".</li> <li>4) Scroll through the available selections: <b>Enable</b> or <b>Disable</b>.</li> <li>5) * Display flashes "<b>Strd</b>" message and advances to "Soak Enable/Disable" submenu.</li> </ol>
	Press ENTER Press MAX Press ENTER	<p><b>SOAK ENABLE/DISABLE SUBMENU:</b></p> <ol style="list-style-type: none"> <li>6) Display flashes "<b>Enbl</b>" or "<b>d5bl</b>".</li> <li>7) Scroll through the available selections: <b>Enable</b> or <b>Disable</b>.</li> <li>8) Display flashes "<b>Strd</b>" message and advances to "Ramp Value" submenu.</li> </ol>

**Note**

Ramp & Soak provides users with the flexibility to slowly bring the process variable to the desired set point. Ramp & Soak Values are specified in HH.MM format. The Ramp Value indicates the time specified to bring the process variable to Setpoint 1. Once setpoint is reached, the PID takes over and the process variable will be controlled at the desired setpoint indefinitely. If Soak is enabled, PID will control the process variable at the specified setpoint for the duration of soak time and then will turn off Output 1. To start a new ramp/soak cycle, reset the controller by pressing MENU and then MIN button. An active ramp/soak will change SP1 one degree above the PV and will cause the most significant digit to blink. The SP1 will be incremented by one degree until it reaches the original SP1. The minimum ramp time must be at least twice the time that it will take the PV to reach the SV with OUT1 fully ON.

\* **NOTE:** If "Ramp" Disable was selected, the display skips "Soak" submenu to the next menu item.

## Ramp & Soak cont.

Display	Action	Response
	Press ENTER	<b>RAMP VALUE SUBMENU:</b> 9) Display flashes 1st digit of previous " <i>rANP</i> " value.
	Press MAX & MIN	10) Press MAX and MIN buttons to enter a new " <i>rANP</i> " value.
	Press ENTER	11) Display flashes " <i>Strd</i> " message and advances to "Soak Value" submenu.
	Press ENTER	<b>SOAK VALUE SUBMENU:</b> 9) Display flashes 1st digit of previous "Soak" value.
	Press MAX & MIN	10) Press MAX and MIN buttons to enter a new "Soak" value.
	Press ENTER	11) Display flashes " <i>Strd</i> " message and advances to the "Analog Output".

**Note**

The Ramp & Soak time is 00:00 to 99:59 i.e. HH.MM.(from zero to 99 hours and 59 minutes)

**During Ramp & Soak do not perform any operations or settings before first pressing MENU and MIN buttons or using software disable Ramp. Any alarms or other output are disabled during this time.**


### 3.3 Available Options

---

The Controller may be ordered with one of the three following options:




- 1) **Analog Output:** This option provides additional flexibility to transmit the equivalent value of process variable to other devices using a 4 to 20 mA current loop or 0-10 V signal.
- 2) **Communication Option:** This option makes the controller a very powerful instrument providing the user with even greater capability since all the parameters can be transmitted via a personal computer.
- 3) **Remote Setpoint:** One of the three already stored setpoints can be activated.

## Analog Output Option








**Figure 3.9** *Flowchart for Analog Output Option*

OPERATION: *CONFIGURATION MODE***Analog Output Option *cont.***

Display	Action	Response
	Press MENU Press ENTER	<ol style="list-style-type: none"> <li>1) Press MENU, if necessary, until the "<b>AnLG Out</b>" prompt appears.</li> <li>2) Display advances to "Analog Type" submenu.</li> </ol>
	Press MENU	<p><b>IF THE ANALOG OUTPUT OPTION IS NOT INSTALLED, THE CONTROLLER WILL SHOW "<i>not - InSt</i>"</b></p> <p>Press MENU, if you receive the "Not Installed" message and advance to the "Communication" submenu.</p>
	Press ENTER Press MAX Press ENTER	<p><b>ANALOG RETRANSMISSION TYPE SUBMENU:</b></p> <ol style="list-style-type: none"> <li>3) Display flashes "<b>vOLT</b>" or "<b>CUrr</b>".</li> <li>4) Scroll through the available selections: Volt or Current.</li> <li>5) Display flashes "stored" message and advances to "Reading 1" of the Output Reading submenu.</li> </ol>

**Analog Output Option *cont.***

Display	Action	Response
	Press ENTER Press MAX & MIN Press ENTER	<b>READING 1</b> 6) Display flashes 1st digit of previous "Reading 1" value. 7) Enter "Reading 1" value. 8) Display advances to " <b>out 1</b> ".
	Press ENTER Press MAX & MIN Press ENTER	<b>OUT 1</b> 9) Display flashes 1st digit of previous "Out 1" value. 10) Enter "Out 1" value. 11) Display advances to "Reading 2".
	Press ENTER Press MAX & MIN Press ENTER	<b>READING 2</b> 12) Display flashes 1st digit of previous "Reading 2" value. 13) Enter "Reading 2" value. 14) Display advances to " <b>out 2</b> ".
	Press ENTER Press MAX & MIN Press ENTER	<b>OUT 2</b> 15) Display flashes 1st digit of previous "Out 2" value. 16) Enter "Out 2" value. 17) Display advances to the "Communication Option" menu.
		<b>Note</b>  The above example is for 0-10 of the entire range of the process input and analog output. For 0-20 mA output all you need is to set "Out 2" to <b>2000</b> .

## Communication Option












Figure 3.10 Flowchart for Communication Option






## Communication Option *cont.*

Display	Action	Response
	Press MENU Press ENTER	<ol style="list-style-type: none"><li>1) Press MENU, if necessary, until the "<b>COM OPTn</b>" prompt appears.</li><li>2) Display advances to "Communication Parameters" submenu.</li></ol>
	Press MENU	<p><b>IF THE COMMUNICATION OPTION IS NOT INSTALLED, THE CONTROLLER WILL SHOW "not - Inst"</b></p> <p>Press MENU, if you receive the "Not Installed" message and advance to the "Remote Setpoint" menu.</p>
	Press ENTER	<p><b>COMMUNICATION PARAMETERS SUBMENU:</b></p> <p>Display shows "Communication Parameters" prompt.</p> <ol style="list-style-type: none"><li>3) Display advances to "<b>baud</b>" submenu.</li></ol>
	Press ENTER Press MAX Press ENTER	<p><b>BAUD SUBMENU:</b></p> <ol style="list-style-type: none"><li>4) Display flashes previous selection for "BAUD" value.</li><li>5) Scroll through the available selections: <b>300, 600, 1200, 2400, 4800, 9600, 19.2K.</b></li><li>6) Display flashes "<b>Strd</b>" message and advances to "Parity" submenu.</li></ol>

OPERATION: *CONFIGURATION MODE***Communication Option cont.**

Display	Action	Response
	Press ENTER Press MAX Press ENTER	<b>PARITY SUBMENU:</b> 7) Display flashes previous selection for "Parity". 8) Scroll through the available selections: <b>NO, ODD, EVEN</b> . 9) Display flashes " <b>Strd</b> " message and advances to "Data Bit" submenu.
	Press ENTER Press MAX Press ENTER	<b>DATA BIT SUBMENU:</b> 7) Display flashes previous selection for "Data Bit". 8) Scroll through the available selections: <b>7 BIT, 8 BIT</b> . 9) Display flashes " <b>Strd</b> " message and advances to "Stop Bit" submenu.
	Press ENTER Press MAX Press ENTER	<b>STOP BIT SUBMENU:</b> 7) Display flashes previous selection for "Stop Bit". 8) Scroll through the available selections: <b>1 BIT, 2 BIT</b> . 9) Display flashes " <b>Strd</b> " message and advances to "BUS FORMAT" submenu.
	Press ENTER	<b>BUS FORMAT SUBMENU:</b> Display shows " <b>buS Frnt</b> " prompt.  10) Display advances to "Check Sum" submenu.

## Communication Option *cont.*

Display	Action	Response
	Press ENTER Press MAX Press ENTER	<b>LINE FEED SUBMENU:</b> 14) Display flashes previous selection for "Line Feed". 15) Scroll through the available selections: <b>NO, YES</b> . 16) Display flashes " <b>Strd</b> " message and advances to "ECHO" submenu.
	Press ENTER Press MAX Press ENTER	<b>ECHO SUBMENU:</b> 17) Display flashes previous selection for "ECHO". 18) Scroll through the available selections: <b>NO, YES</b> . 19) Display flashes " <b>Strd</b> " message and advances to "Standard" submenu.
	Press ENTER Press MAX Press ENTER	<b>STANDARD SUBMENU:</b> 20) Display flashes previous selection for "Standard". 21) Scroll through the available selections: <b>232C, 485</b> . 22) Display flashes " <b>Strd</b> " message and advances to "Mode" submenu.

**Note**

By setting standard to 485, the device will only respond to commands to its serial port that include the address, as selected on the following pages. (Transmit Time Section)





OPERATION: *CONFIGURATION MODE***Communication Option *cont.***

Display	Action	Response
	Press ENTER Press MAX Press ENTER	<b>MODE SUBMENU:</b> 23) Display flashes previous selection for "Mode". 24) Scroll through the available selections: <b>CMND</b> , <b>CONT</b> (command, continuous). 25) Display flashes " <b>Strd</b> " message and advances to "Separation" submenu.
	Press ENTER Press MAX Press ENTER	<b>SEPARATION SUBMENU:</b> 26) Display flashes previous selection for "Separation". 27) Scroll through the available selections: <b>SPCE</b> , <b>CR</b> (space, carriage return). 28) Display flashes " <b>Strd</b> " message and advances to "Data Format" submenu.
	Press ENTER	<b>DATA FORMAT SUBMENU:</b> Display shows " <b>dAtA Frnt</b> " prompt. This menu is applicable for continuous mode of RS-232 communication. 32) Display advances to "Status" submenu.





**Note**

The Data Format options determine what readings and values will be returned in the data string sent from the unit either when operating in Continuous Mode or when receiving a Send-Data-String request via the serial port.



OPERATION: *CONFIGURATION MODE***Communication Option *cont.***

Display	Action	Response
	Press ENTER Press MAX Press ENTER	<b>STATUS SUBMENU:</b> 33) Display flashes previous selection for "Status" (alarm status). 34) Scroll through the available selections: <b>NO, YES.</b> 35) Display flashes " <b>Strd</b> " message and advances to "Reading" submenu.
	Press ENTER Press MAX Press ENTER	<b>READING SUBMENU:</b> 36) Display flashes previous selection for "Reading". 37) Scroll through the available selections: <b>NO, YES.</b> 38) Display flashes " <b>Strd</b> " message and advances to "Peak" submenu.
	Press ENTER Press MAX Press ENTER	<b>PEAK SUBMENU:</b> 39) Display flashes previous selection for "Peak". 40) Scroll through the available selections: <b>NO, YES.</b> 41) Display flashes " <b>Strd</b> " message and advances to "Valley" submenu.
	Press ENTER Press MAX Press ENTER	<b>VALLEY SUBMENU:</b> 42) Display flashes previous selection for "Valley". 43) Scroll through the available selections: <b>NO, YES.</b> 44) Display flashes " <b>Strd</b> " message and advances to "Unit" submenu.

OPERATION: *CONFIGURATION MODE***Communication Option cont.**

Display	Action	Response
	Press ENTER Press MAX Press ENTER	<b>UNIT SUBMENU:</b> 45) Display flashes previous selection for "Unit". 46) Scroll through the available selections: <b>NO, YES.</b> 47) Display flashes " <b>Strd</b> " message and advances to "ID" submenu.
	Press ENTER Press MAX Press ENTER	<b>ID SUBMENU: NOT INSTALLED</b> 48) Display flashes previous selection for "ID". 49) Scroll through the available selections: <b>NO, YES.</b> 50) Display flashes " <b>Strd</b> " message and advances to "Address Setup" submenu.
	Press ENTER	<b>ADDRESS SETUP SUBMENU: .</b> Display shows " <b>Addr StUP</b> " prompt. This menu is applicable to the RS-485 option only. 51) Display advances to "Address Value" (0000 to 0199) submenu.
	Press ENTER Press MAX & MIN Press ENTER	<b>ADDRESS VALUE SUBMENU:</b> 52) Display flashes 1st digit of previous address value. 53) Enter new address value. 54) Display flashes " <b>Strd</b> " message and advances to "Transmit Time" submenu. If no change press "Menu" to go on.

## Communication Option *cont.*

Display	Action	Response
		<b>TRANSMIT TIME SUBMENU:</b> Display shows "t r t , S t u P" prompt. This menu is applicable if Continuous Mode was selected.
	Press ENTER	55) Display advances to "Transmit Time Value" submenu.
		<b>TRANSMIT TIME VALUE SUBMENU:</b>
	Press ENTER	56) Display flashes 1st digit of previous transmit time in seconds.
	Press MAX & MIN	57) Enter new transmit time, e.g. 0030 will send every 30 seconds the data in Continuous Mode.
	Press ENTER	58) Display flashes "S t r d" message and advances to "Remote Setpoint" menu. If no change press "Menu" to go on.

**Note**

Transmit time can be set from 0 to 9999.

## COMMUNICATION COMMANDS (Table 3.1)

Command Prefix (Command Class)	Meaning
^AE	Special read, Communication parameters
P (Put)	Write HEX data into RAM
W (Write)	Write HEX data into EEPROM. <b>1,000,000 writes to EEPROM is guaranteed!</b>
G (Get)	Read HEX data from RAM
R (Read)	Read HEX data from EEPROM
U	Read status byte
V	Read measurement data string in decimal format
X	Read measurement data values in decimal format
D	Disable
E	Enable
Z	Reset

## Command Formats

For "P" and "W" Command Classes:	For "G" and "R" Command Classes:	For "X", "V", "U", "D", "E" and "Z" Command Classes:
<b>Point-to-point mode:</b> * ccc [<data>] <CR>	<b>Point-to-point mode:</b> * ccc <CR>	<b>Point-to-point mode:</b> * ccc <CR>
<b>Multipoint mode:</b> * ncccc [<data>] <CR>	<b>Multipoint mode:</b> * ncccc <CR>	<b>Multipoint mode:</b> * ncccc <CR>



---

## Command Formats *cont.*

---

Where "\*" is the selected Recognition Character. You may select any ASCII table symbol from "!" (HEX address "21") to the right-hand brace (HEX "7D") except for the caret "^", "A", "E", which are reserved for bus format request. "(nn)" are the two ASCII characters for the device Bus Address. Use values from "00" to hex "C7" (199 decimal).

"ccc" stands for the hex-ASCII Command Class letter (one of eleven given in table 3.12), followed by the two Hex-ASCII Command Suffix characters identifying the meter data, features or menu items to which the command is directed (given in table 3.13).

"<data>" is the string of characters containing the variable information the computer is sending to the meter. These data (whether BCD or binary) are encoded into Hex-ASCII characters, two characters to the byte. Square brackets (indicating optional status) enclose this <data> string, since some commands contain no data.

"<nn>" is the device address for RS-485 communication and the max is 199 in decimal.

---

### Examples:

1. To reset the controller, send \*Z02 (Table 3.1)
2. To read Setpoint 1, send \*R01 (Table 3.2)
3. To change Setpoint 1 to 100.0

OPERATION: *CONFIGURATION MODE***Command Formats cont.**

**Description:** SETPOINT.23 ~ 0 means 3 bytes x 8 bit positions (2 characters in each byte).

**SETPOINT.23** = 0 = positive sign  
1 = negative sign

**SETPOINT.22~20** = 000 - Not Allowed

001 - Decimal Point 1 (XXXX.)

010 - Decimal Point 1 (XXX.X)

011 - Decimal Point 1 (XX.XX)

101 - Decimal Point 1 (X.XXX)

\*Process Only

**SETPOINT.19~0** = Setpoint data

For 100.0: Positive sign = 0, Decimal Point 2 = 010 Bin, Setpoint data 1000 = 3E8 Hex = 001111101000 Bin

The command data = 0010 0000 0000 0011 1110 1000 Bin = 2003E8 Hex  
**A 0 0 3 E 8** Hex

Send \*W01 2 003E8, where

\*W01 - \*<ccc> - write to Setpoint 1 (Table 3.1)

2003E - <data> - Setpoint data including sign and decimal point (Table 3.2)

---

## Command Formats *cont.*

---

**Note** No spaces are allowed in the data string. The spaces provided in the previous example are for illustration purposes only.

**Note** Decimal Point position for TC/RTD = 1 or 2, for PROCESS = 1, 2, 3, or 4.

**Note** Decimal Point position for setpoint should be the same as Decimal Point position sets for Process Value and can not be overwritten by SETPOINT command. (See RDGCNG command, described below.)

#### 4. To change Setpoint 1 to -100.0

For (-100.0): Negative sign = 1, Decimal Point 2 = 010 Bin, Setpoint data 1000 = 3E8 Hex = 001111101000 Bin

The command data = 1010 0000 0000 0011 1110 1000 Bin = A003E8 Hex

**A 0 0 3 E 8**

Send \*W01A003E8

#### 5. To send the same as above for RS-485 of transit address 01 the command is \*01W01A03E8.

**Note** Default settings are Recog. Char. "\*", 9600 bps, 7 data, 1 stop, and Odd Parity.

OPERATION: *CONFIGURATION MODE*

<b>COMMAND LETTERS AND INDEX (Table 3.2)</b>					
<b>Command</b>	<b>Command Index</b>	<b>Function</b>	<b>Command Bytes</b>	<b>#OF Characters</b>	<b>Default Value</b>
RW	01	SP1	3	6	200000
RW	02	SP2	3	6	200000
GPRW	03	RDGOFF	3	6	200000
RW	05	ID	2	4	0000
-	06	N/A	-	-	
RW	07	INPUT	1	2	04
GPRW	08	RDGCNF	1	2	4A
RW	09	AL1CNFG	1	2	00
RW	0B	LOOP BREAK TIME	2	4	003B
RW	0C	OUT1CNF	1	2	81
RW	0D	OUT2CNF	1	2	60
RW	0E	RAMPTIME	2	4	0000
RW	10	COMM.PARAMETERS	1	2	0D
RW	12	AL1LO	3	6	A003E8
RW	13	AL1HI	3	6	201170
GPRW	14	RDGSCL	3	6	100001

## OPERATION: CONFIGURATION MODE

### COMMAND LETTERS AND INDEX *cont.*

Command	Command Index	Function	Command Bytes	#OF Characters	Default Value
GPRW	17	PB1/DEAD BAND	2	4	00C8
GPRW	18	RESET 1	2	4	00B4
GPRW	19	RATE 1	2	4	0000
GPRW	1A	CYCLE 1	1	2	07
-	1B	N/A	-	-	
GPRW	1C	PB2/DEAD BAND	2	4	00C8
GPRW	1D	CYCLE 2	1	2	07
RW	1E	SOAK TIME	2	4	0000
RW	1F	BUS FORMAT	1	2	14
GPRW	20	DATA FORMAT	1	2	02
RW	21	ADDRESS	1	2	01
RW	22	TRANSMIT TIME INTERVAL	2	4	0010
RW	25	C.J.OFFSET ADJ.	3	6	200000
RW	26	RECOGNITION CHARACTER	1	2	2A

### COMMAND LETTERS AND INDEX *cont.*

Command	Command Index	Function
D	01	DISABLE ALARM 1
D	03	STANDBY
D	04	DISABLE SELF
E	01	ENABLE ALARM 1
E	03	DISABLE STANDBY
E	04	ENABLE SELF
X	01	SEND MAIN READING
X	02	SEND PEAK READING
X	03	SEND VALLEY READING
X	04	SEND READING
X	05	SEND READING
U	01	SEND ALARM STATUS
U	03	SEND SW VERSION
V	01	SEND DATA STRING
Z	02	HARD RESET

**Note** Except for Setpoints and Alarms, modifying and setting of the menu configuration should be followed by the RESET Command.

OPERATION: *CONFIGURATION MODE***Command Formats**

**Description:** INPUT.76543210 means 8 bit positions of the Input Command Data (Operand).

<b>INPUT.76</b> = 00 = 100 ohm RTD	<b>INPUT.5432</b> = 0000 J/392-2/0-100 mV	<b>INPUT.10</b> = 00 TC
01 = 500 ohm RTD	0001 K/392-3/0-1 V	01 RTD
10 = 1000 ohm	0010 T/392-4/0-10 V	10 PC
	0011 E/385.2/0-20 mA	11 N/C
	0100 N/385.3	
	0101 DIN-J/385.4	
	0110 R	
	0111 S	
	1000 B	
	1001 C	

**Example:** Set RTD, 4-wire, .00392 Curve, 100 m ohms. The command data is 00001001Bin = 09Hex. Send \*W0709.

**Note** Send Read Command first to determine the bits which are not specified for some positions (TC, PC for positions 7, 6 above).

---

## Command Formats *cont.*

---

**RDGCNF.210** = 000 Not Allowed

001 Decimal Point 1 (XXXX.)

010 Decimal Point 2 (XXX.X)

011 Decimal Point 3\* (XX.XX)

100 Decimal Point 4\* (X.XXX)

\*Process only

**RDGCNFG.3** = 0 °C

1 °F

**RDGCNFG.765** = 000 Filter constant 1

001 Filter constant 2

010 Filter constant 4

011 Filter constant 8

100 Filter constant 16

101 Filter constant 32

110 Filter constant 64

111 Filter constant 128

**Example:** Set Decimal Point 1, °C, Filter constant 16. The command data is 10000001Bin = 81Hex. Send \*W0881.

**Note** Send a Read Command first to determine the proper Decimal Point position (\*R08).

---

OPERATION: *CONFIGURATION MODE***Command Formats *cont.***

**AL1CNFG.0** = 0 Disable  
1 Enable

**AL1CNFG.1** = 0 Absolute  
1 Deviation

**AL1CNFG.2** = 0 Unlatch  
1 Latch

**AL1CNFG.3** = 0 Normally Open  
1 Normally Closed

**AL1CNFG.54** = 00 Above  
01 Below  
10 Hi/Lo  
\* 11 Band  
\* Deviation Only

**AL1CNFG.6** = 0 Loop Break Alarm Disable  
1 Loop Break Alarm Enable

**AL1CNFG.7** = 0 Alarm Power On Enable  
1 Alarm Power On Disable

**Example:** Set Alarm 1 Enable, Deviation, Unlatch, N.C., Band, Loop Disable, Alarm Power On Enable. The command data is 10111011Bin = BBHex. Send \*W09BB.



---

## Command Formats *cont.*

---

**Time Proportional:** OUT1CNFG.0 = 0 On/off  
1 PID

**Analog Proportional:** OUT1CNFG.6 = 0 0 - 20 mA  
1 4 - 20 mA

**OUT1CNFG.1** = 0 Reverse  
1 Direct

**OUT1CNFG.2** = 0 Auto PID Disable  
1 Auto PID Enable

**OUT1CNFG.3** = 0 Adaptive Disable  
1 Adaptive Enable

**OUT1CNFG.4** = 0 Anti Wind Up Disable  
1 Anti Wind Up Enable

**OUT1CNFG.5** = 0 Auto PID Stop  
1 Auto PID Start

**Example:** Set PID, Direct, Auto PID Enable, Adaptive Enable, Anti Integral Disable, Auto PID Start. The command data is 00101111Bin = 2FHex. Send \*W0C17.

---

## OPERATION: *CONFIGURATION MODE*

---

### Command Formats *cont.*

---

**OUT2CNFG.0** = 0 On/off  
1 PID

**OUT2CNFG.1** = 0 Reverse  
1 Direct

**OUT2CNFG.2** = 0 Manual PID  
1 Auto PID

**OUT2CNFG.3** = 0 Ramp Disable  
1 Ramp Enable

**OUT2CNFG.4** = 0 Soak Disable  
1 Soak Enable

**OUT2CNFG.765** = 000 Damping 1  
001 Damping 2  
010 Damping 3  
011 Damping 4  
100 Damping 5  
101 Damping 6  
110 Damping 7  
111 Damping 8

**Example:** Set On/Off, Reverse, Auto PID Disable, Ramp, Disable, Soak Disable, Damping 5. The command data is 10000000Bin = 80Hex. Send \*W0D85.

---

---

## Command Formats *cont.*

---

<b>COMM.PARAMETERS.210</b> = 000	300	BAUD	<b>COMM. PARAMETERS.43</b> = 00	No Parity
	001	600		01 Odd
	010	1200		10 Even
	011	2400		11 N/A
	100	4800		
	101	9600		
	110	19200		

<b>COMM. PARAMETERS.5</b> = 0	7 Bit Data	<b>COMM. PARAMETERS.6</b> = 0	1 Stop Bit
1	8 Bit Data	1	2 Stop Bit

**Example:** Set Baud 9600, Odd, 7 Bit, 1 Stop. The command data is 00001101Bin = 0DHex. Send \*W100D.

---

<b>BUSFORMAT.0</b> = N/A	<b>BUS FORMAT.1</b> = 0 No LF	<b>BUS FORMAT.2</b> = 0 No Echo
	1 LF	1 Echo
<b>BUSFORMAT.3</b> = 0 RS-232	<b>BUS FORMAT.4</b> = 0 Continuous	<b>BUS FORMAT.5</b> = 0 CR
1 RS-485	1 Command	1 Space

**Example:** Set Space, Continuous, RS-232, Echo, Line Feed, N/A. The command data is 00000110Bin = 06Hex. Send \*W1F06.


---

## OPERATION: *CONFIGURATION MODE*

---

### Command Formats *cont.*


---


**Note**  DATAFORMAT is used for V01 command or Continuous Mode (RS-232).

<b>DATAFORMAT.0</b> = 0 No Status 1 Alarm Status	<b>DATAFORMAT.1</b> = 0 No Reading 1 Reading	<b>DATAFORMAT.2</b> = 0 No Peak 1 Peak
<b>DATAFORMAT.3</b> = 0 No Valley 1 Valley	<b>DATAFORMAT.6</b> = 0 No Unit 1 Unit	<b>DATAFORMAT.7</b> = N/A

**Example:** Set Space, Continuous, RS-232, Echo, Line Feed, N/A. The command data is 00000110Bin = 06Hex. Send \*W1F06.

---

**Note**  **ADDRESS** is applicable for RS-485 and can be 01 to 199.

**Note**  **TRANSMIT TIME INTERVAL** is applicable in the RS-232 Continuous Mode which specifies the time between transmissions and the minimum time is 1 second.

---

---

## Command Formats *cont.*

---

**RDGOFF.0~19** = Offset Data

**RDGOFF.20~22** = DP+2

**RDGOFF.23** = 0 Positive Offset  
1 Negative Offset

**RDGSC.0~18** = Scale Data

**RDGSC.19** = 0 Direct Scale  
1 Reverse Scale

**RDGSC.20~23** = DP+1

**Example:** To have an input of 4 to 20 mA displayed as 0 to 100,  
The Low input value = min. input value \* conversion number = 4(mA) x 500 = 2000  
The High input value = max. input value \* conversion number = 20(mA) x 500 = 10000 (9999)  
where: conversion number is a coefficient of conversion between input values and real display range.  
The full range of the display = 10000, conversion number = 10000/20 = 500.

OPERATION: *CONFIGURATION MODE***Reading Scale**

Scale = (UD - LD)/(UI - LI), where: UD - Upper Display, LD - Low Display

UI - Upper Input, LI - Low Input

Scale = (100 - 0)/(9999-2000) = 0.0125016 (These values were obtained from example on previous Section 3: Reading Configuration with Process)

0.0125016 = 125016 x 10<sup>-7</sup>, where 125016 is Reading Scale Data, Decimal Point = 7

RDGSC.23~20 = 8 (DP = 7); RDGSC.19 = 0 (direct scale); RDGSC. 18 ~0 = 1E858Hex (125016 Dec)

Binary Code:

23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
1	0	0	0	0	0	0	1	1	1	1	0	1	0	0	0	0	1	0	1	1	0	0	0

Hex. Code:

**8**

**1**

**E**

**8**

**5**

**8**

Send command: \*W1481E858 (scale = 81E858)


## Reading Offset

Offset = UD - Scale x UI

Offset = 100 - (0.0125) x (10000) = (-25), where Offset data = 25, Decimal Point = 0, Offset is negative.

RDGOFF.23 = 1 (Offset is negative); RDGOFF.22 ~ 20 = 2 (DP = 0); RDGOFF.19 ~ 0 = 00019Hex (25 Dec)

Binary Code:



Hex. Code:

**A**

**0**

**0**

**0**

**1**

**9**

Send command: \*W03A00019 (offset = A00019)

**Note**

To communicate when the Continuous Mode is enabled, the Continuous Mode must be stopped by sending 13 Hex (XOFF) and then send ^AE.

## Remote Setpoint Option

MENU LEVEL  
PRESS MENU

MENU LEVEL 2  
PRESS ENTER

MENU LEVEL  
PRESS ENTER

SELECT DIGIT  
PRESS MIN▼

INCR. DIGIT  
PRESS MAX▲





STORE  
PRESS ENTER




**Figure 3.11** *Flowchart for Remote Setpoint*



OPERATION: *CONFIGURATION MODE***Remote Setpoint Option cont.**

Display	Action	Response
	Press MENU Press ENTER	<ol style="list-style-type: none"> <li>1) Press MENU, if necessary, until the "<b>r.5Et P0nt</b>" prompt appears.</li> <li>2) Display advances to "Remote Setpoint 1" submenu.</li> </ol>
	Press MENU	<p><b>IF THE REMOTE SETPOINT IS NOT INSTALLED, THE CONTROLLER WILL SHOW "NOT INSTALLED".</b></p> <p>Press MENU, if you receive the "Not Installed" message.</p>
	Press ENTER Press MAX & MIN Press ENTER	<p><b>REMOTE SETPOINT 1 SUBMENU:</b></p> <ol style="list-style-type: none"> <li>3) Display flashes 1st digit of previous selection for "Remote Setpoint 1" value.</li> <li>4) Enter a new "Remote Setpoint 1" value.</li> <li>5) Display flashes "<b>5trd</b>" message and advances to "Remote Setpoint 2" submenu.</li> </ol>
	Press ENTER Press MAX & MIN Press ENTER	<p><b>REMOTE SETPOINT 2 SUBMENU:</b></p> <ol style="list-style-type: none"> <li>6) Display flashes 1st digit of previous selection for "Remote Setpoint 2" value.</li> <li>7) Enter a new "Remote Setpoint 2" value.</li> <li>8) Display flashes "<b>5trd</b>" message and advances to "Remote Setpoint 3" submenu.</li> </ol>

## Remote Setpoint Option *cont.*

Display	Action	Response
	Press ENTER Press MAX & MIN Press ENTER	<b>REMOTE SETPOINT 3 SUBMENU:</b> 9) Display flashes 1st digit of previous selection for "Remote Setpoint 3" value. 10) Enter a new "Remote Setpoint 3" value. 11) Display flashes " <b>Strd</b> " message and the display shows "Reset" ending the <i>Configuration Mode</i> .



### RESET:

The controller automatically resets after the last menu of the **Configuration Mode** has been entered. After the controller resets, the controller advances to the **Run Mode**.

**Note**

In order to select *r.SP* remotely connect Bi1 and Bi2 as follows:

	Bi1	Bi2
r.SP.1	GND	GND
r.SP.2	OPEN	GND
r.SP.3	GND	OPEN
Setpoint 1	OPEN	OPEN

## SPECIFICATIONS

**Accuracy:** See the following Specification Chart.

**Resolution:** 1°/0.1°; 10 µV process

**Temperature Stability:** 0.08°C/°C; 50 ppm/°C process

**Thermocouple Cold End Tracking:** 0.05°C/°C

**NMRR:** 60 dB

**CMRR:** 120 dB

**A/D Conversion:** Dual slope

**Reading Rate:** 3 samples per second

**Digital Filter:** Programmable

**Display:** Dual 4-digit, 7-segment LED, 9.2 mm (0.36"); red process variable, green setpoint; indicators for output and alarm status; 7.6 mm (0.3") for NEMA 12 units

**Warmup to Rated Accuracy:** 30 min

### **INPUT**

**Input Types:** Thermocouple, RTD, analog voltage, analog current

**Thermocouple Lead Resistance:** 100 Ω max

RTD Input: 100/500/1000Ω Pt sensor, 2, 3, or 4-wire; 0.00385 or 0.00392 curve

**Voltage Input:** 0 to 100 mV, 0 to 1 V, 0 to 10 Vdc

**Current Input:** 0 to 20 mA (5 ohm load)

**Configuration:** Single-ended

**Polarity:** Unipolar

**Step Response:** 0.7 sec for 99.9%

**Decimal Selection:** None, 0.1, 0.01 or 0.001

**Span Adjustment:** 0.001 to 9999 counts

**Offset Adjustment:** -999 to +9999

### **CONTROL**

**Action:** Reverse (heat) or direct (cool)

**Modes:** Time proportioning and proportional control modes; selectable preset tune, adaptive tune, auto-tune, PID, proportional, proportional with integral, proportional with derivative with anti-reset windup, on-off

**Rate:** 000.0 to 399.9 sec

**Reset:** 0 to 3999 sec

**Cycle Time:** 1 to 199 seconds; set to 0 for on/off operation

**Gain:** 0.5 to 100% of span; setpoints 1 or 2

**Damping:** 0000 to 0008

**Soak:** 00.00 to 99.59 (HH:MM), or off

**Ramp to Setpoint:** 00.00 to 99.59 (HH:MM), or off

**Autotune:** Operator initiated from front panel

### **CONTROL OUTPUT:**

**Relay:** 5 A @ 120 Vac, 3 A @ 240 Vac; configurable for on/off, PID or ramp and soak

**Output 1:** SPDT type

**Output 2:** SPST type

**SSR:** Rated 0.5 A @ 120/240 Vac, continuous

**DC Pulse:** non-isolated; 10 Vdc @ 20 mA

**Analog Output:** 0 to 10 Vdc or 0 to 20 mA; 500 Ω max

### **OPTIONS:**

**Remote Setpoint Selection:** Up to 3 setpoints stored in memory; contact closure selection

## SPECIFICATIONS

---

### **COMMUNICATIONS:**

**RS-232 or RS-485:** 300 to 19.2k baud; completely programmable setup capability; program to transmit current display, alarm status, min/max, actual measured input value and status

**RS-485:** Addressable from 0 to 199

**Connection:** Screw terminals

### **ALARM OUTPUT:**

**Type:** SPST relay, 3 A @ 120 Vac, 3 A @ 240 Vac

**Operation:** High/low, latching/ non-latching, and process/deviation; front panel configurations

### **ANALOG OUTPUT:**

Isolated 0 to 10 Vdc or 0 to 20 mA, programmable

### **INSULATION: (per 1 minute test)**

Power to TC/RTD input: 2300 Vrms

Power to Relay/SSR Outputs: 2300 Vrms

Power to Relay Alarms: 2300 Vrms

Control Relay/SSR to Control Relay/SSR: 2300 Vrms

Relay Alarm 1 to Relay Alarm 2: 2300 Vrms

RS232/RS485/Analog to Alarms/Controls Relay/SSR/Power: 2300 Vrms

RS232/RS485 to Input TC/RTD: 350 Vrms

### **APPROVALS:**

UL, CE per EN50081-1, EN50082-1, EN61010-1

### **GENERAL:**

**Line Voltage:** 90-240 Vac +/-10%, 50-400 Hz

**Power:** 4 Watts

**External Fuse Required:** 100mA/250V Time-Slow-Blow, UL 248-14 Listed  
100mA/250V Time-Lag, IEC 127-3 Listed

**Environmental Condition:** 0 to 55°C (32 to 131°F), 90% RH  
non-condensing

**CN77300 Series:** 48 H x 48 W x 123.3 mm D (1.89" x 1.89" x 4.85");

**CN77500 Series:** 53 H x 53 W x 123.3 mm D (2.1" x 2.1" x 4.85");

**Panel Cutout:** 45 mm (1.777") square,  $\frac{1}{16}$  DIN

**CN77R300 Series:** 48 H x 48 W x 135 mm D (1.89" x 1.89" x 5.32");

**CN77R500 Series:** 53 H x 53 W x 135 mm D (2.1" x 2.1" x 5.32");

**Panel Cutout:** 44.5 mm (1.75") dia round

**Weight:** 227 g (0.5 lb)

# SPECIFICATIONS

	Input Type	Range	Accuracy*
<b>J</b>	Iron-Constantan	-210 to 760°C -346 to 1400°F	0.4°C 0.7°F
<b>K</b>	CHROMEKA®-ALOMEGA®	-270 to -160°C -160 to 1372°C -454 to -256°F -256 to 2502°F	1.0°C 0.4°C 1.8°F 0.7°F
<b>T</b>	Copper-Constantan	-270 to -190°C -190 to 400°C -454 to -310°F -310 to 752°F	1.0°C 0.4°C 1.8°F 0.7°F
<b>E</b>	CHROMEKA-Constantan	-270 to -220°C -220 to 1000°C -454 to -364°F -364 to 1832°F	1.0°C 0.4°C 1.8°F 0.7°F
<b>R</b>	Pt/13%Rh-Pt	-50 to 40°C 40 to 1788°C -58 to 104°F 104 to 3250°F	1.0°C 0.5°C 1.8°F 0.9°F
<b>S</b>	Pt/10%Rh-Pt	-50 to 100°C 100 to 1768°C -58 to 212°F 212 to 3214°F	1.0°C 0.5°C 1.8°F 0.9°F
<b>B</b>	30%Rh-Pt/ 6%Rh-Pt	200 to 640°C 640 to 1820°C 212 to 1184°F 1184 to 3308°F	1.0°C 0.5°C 1.8°F 0.9°F

	Input Type	Range	Accuracy*
<b>C</b>	5%Re-W/ 26%Re-W	0-2354°C 32-4253°F	0.4°C 0.7°F
<b>N</b>	Nicrosil-Nisil	-250 to -100°C -100 to 1300°C -418 to -148°F -148 to 2372°F	1.0°C 0.4°C 1.8°F 0.7°F
<b>L</b>	J DIN	-200 to 900°C -328 to 1652°F	0.4°C 0.7°F
<b>RTD</b>	Pt, 0.00385, 100Ω, 500Ω, 1000Ω	200 to 900°C -328 to 1652°F	0.4°C 0.7°F
<b>RTD</b>	Pt, 0.00392, 100Ω, 500Ω, 1000Ω	-200 to 850°C -328 to 1562°F	0.4°C 0.7°F
<b>PROCESS</b>			
	Voltage	0 to 100mV, 0 to 1V, 0 to 10Vdc	0.03% rdg 0.03% rdg
	Current	0 to 20mA, 4 to 20 mA	0.03% rdg



# CE APPROVAL INFORMATION

## 1. Electromagnetic Compatibility (EMC)

This device conforms with requirements of EMC Directive 89/336/EEC, amended by 93/68/EEC. This instrument complies with the following EMC Immunity Standards as tested per EN 50082-2, 1995 (Industrial environment)

Phenomena	Test Specification	Basic Standard
Electrostatic Discharge	+/- 4 kV contact discharge +/- 8 kV air discharge	IEC 1000-4-2 Performance Criteria B
Radio Frequency electromagnetic field.	27 - 1000 MHz 10 V/m 80% AM (1 KHz)	IEC 1000-4-3 Performance Criteria A
Radio Frequency electromagnetic field. Pulse modulated.	900 MHz 10 V/m 50% Duty cycle @ 200 Hz	IEC 1000-4-3 Performance Criteria A
Fast Transients	+/- 2 kV (ac mains) +/- 1 kV (dc, signal I/O) 5/50 ns Tr/Th, 5 KHz rep. freq.	IEC 1000-4-4 Performance Criteria B
Radio Frequency conducted	0.15 - 80 MHz 10 V/m 80% AM (1 KHz)	IEC 1000-4-6 Performance Criteria A

This instrument complies with the following EMC Emission Standards as tested per EN 50081-1, 1992 (Residential, Commercial and Light Industrial)

Phenomena	Frequency Range	Limits	Basic Standard
Radiated Emission	30-230 MHz 230-1000 MHz	30 dB_V/m at 10 m 37 dB_V/m at 10 m quasi peak	CISPR 22 Class B
Conducted Emission	0.15-0.5 MHz 0.5-5 MHz 5-30 MHz	66-56 dB_V quasi peak 56 dB_V quasi peak 60 dB_V quasi peak	CISPR 22 Class B

## 2. Safety

This device conforms with Low Voltage Directive 73/23/EEC, amended by 93/68/EEC. The following LVD requirements have been met to comply with EN 61010-1, 1993 (Electrical equipment for measurement, control and laboratory use)

1. Pollution Degree 2
2. Installation Category II
3. Double Insulation
4. Class I Equipment (90-240 Vac Powered Units)

# Warranty

OMEGA ENGINEERING, INC. warrants this unit to be free of defects in materials and workmanship for a period of 13 months from date of purchase. OMEGA Warranty adds an additional one (1) month grace period to the normal one (1) year product warranty to cover handling and shipping time. This ensures that OMEGA's customers receive maximum coverage on each product.

If the unit should malfunction, it must be returned to the factory for evaluation. OMEGA's Customer Service Department will issue an Authorized Return (AR) number immediately upon phone or written request. Upon examination by OMEGA, if the unit is found to be defective it will be repaired or replaced at no charge. However, this WARRANTY is VOID if the unit shows evidence of having been tampered with or shows evidence of being damaged as a result of excessive corrosion; or current, heat, moisture or vibration; improper specification; misapplication; misuse or other operating conditions outside of OMEGA's control. Components which wear or which are damaged by misuse are not warranted. These include contact points, fuses, and triacs.

In addition to our standard warranty period, OMEGA will extend the warranty period for one (1) additional year only if the warranty card enclosed with each instrument is returned to OMEGA.

**OMEGA is glad to offer suggestions on the use of its various products. Nevertheless, OMEGA warrants only that the parts manufactured by it will be as specified and free of defects. OMEGA MAKES NO OTHER WARRANTIES OR REPRESENTATIONS OF ANY KIND WHATSOEVER, EXPRESSED OR IMPLIED, EXCEPT THAT OF TITLE, AND ALL IMPLIED WARRANTIES INCLUDING ANY WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY DISCLAIMED. LIMITATION OF LIABILITY: The remedies of purchaser set forth herein are exclusive and the total liability of OMEGA with respect to this order, whether based on contract, warranty, negligence, indemnification, strict liability or otherwise, shall not exceed the purchase price of the component upon which liability is based. In no event shall OMEGA be liable for consequential, incidental or special damages.**

Every precaution for accuracy has been taken in the preparation of this manual; however, OMEGA neither assumes responsibility for any omissions or errors that may appear nor assumes liability for any damages that result from the use of the products in accordance with the information contained in the manual.

**SPECIAL CONDITIONS:** Should this equipment be used in any nuclear installation or activity, purchaser will indemnify OMEGA and hold OMEGA harmless from any liability or damage whatsoever arising out of the use of the equipment in such a manner.

# Return Requests

Direct all warranty and repair request/inquiries to the OMEGA Customer Service Department. BEFORE RETURNING ANY PRODUCT(S) TO OMEGA, PURCHASER MUST OBTAIN AN AUTHORIZED RETURN (AR) NUMBER FROM OMEGA'S CUSTOMER SERVICE DEPARTMENT (IN ORDER TO AVOID PROCESSING DELAYS). The assigned AR number should then be marked on the outside of the return package and on any correspondence.

The purchaser is responsible for shipping charges, freight, insurance and proper packaging to prevent breakage in transit.

FOR **WARRANTY** RETURNS, please have the following information available BEFORE contacting OMEGA:

1. P.O. number under which the product was PURCHASED,
2. Model and serial number of the product under warranty, and
3. Repair instructions and/or specific problems relative to the product.

FOR **NON-WARRANTY** REPAIRS, consult OMEGA for current repair charges. Have the following information available BEFORE contacting OMEGA:

1. P.O. number to cover the COST of the repair,
2. Model and serial number of product, and
3. Repair instructions and/or specific problems relative to the product.

It is the policy of OMEGA to make running changes, whenever an improvement is possible. This affords our customers the latest in technology and engineering.

OMEGA is a registered trademark of OMEGA ENGINEERING, INC.

© Copyright 2001 OMEGA ENGINEERING, INC. All rights reserved. This documentation may not be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form, in whole or in part, without prior written consent of OMEGA ENGINEERING, INC.

**PATENT NOTICE:** The "Meter Case Bezel Design" is a trademark of NEWPORT Electronics, Inc., registered in the U.S. USED UNDER LICENSE. This product is covered by one or more of the following patents: U.S. Pat. No. Des. 336,895; 5,274,577/ FRANCE BREVET No. 91 12756/ UK PATENT No. GB2 248 954; GB2 249 837/ SPAIN 2039150; 2048066 / ITALY 1249456; 1250938/ CANADA 2052599; 2052600/ GERMANY DE 41 34398 C2. Other US and International Patents pending or applied for.

# Where Do I Find Everything I Need for Process Measurement and Control? OMEGA...Of Course! *Shop on line at [www.omega.com](http://www.omega.com)*

## **TEMPERATURE**

- ☑ Thermocouple, RTD & thermistor Probes, Connectors, Panels & Assemblies
- ☑ Wire: Thermocouple, RTD & Thermistor
- ☑ Calibrators & Ice Point References
- ☑ Recorders, Controllers & Process Monitors
- ☑ Infrared Pyrometers

## **PRESSURE, STRAIN AND FORCE**

- ☑ Transducers & Strain Gauges
- ☑ Load Cells & Pressure Gauges
- ☑ Displacement Transducers
- ☑ Instrumentation & Accessories

## **FLOW/LEVEL**

- ☑ Rotameters, Gas Mass Flowmeters & Flow Computers
- ☑ Air Velocity Indicators
- ☑ Turbine/Paddlewheel Systems
- ☑ Totalizers & Batch Controllers

## **pH/CONDUCTIVITY**

- ☑ pH Electrodes, Testers & Accessories
- ☑ Benchtop/Laboratory Meters
- ☑ Controllers, Calibrators, Simulators & Pumps
- ☑ Industrial pH & Conductivity Equipment

## **DATA ACQUISITION**

- ☑ Data Acquisition & Engineering Software
- ☑ Communications-Based Acquisition Systems
- ☑ Plug-in Cards for Apple, IBM & Compatibles
- ☑ Datalogging Systems
- ☑ Recorders, Printers & Plotters

## **HEATERS**

- ☑ Heating Cable
- ☑ Cartridge & Strip Heaters
- ☑ Immersion & Band Heaters
- ☑ Flexible Heaters
- ☑ Laboratory Heaters

## **ENVIRONMENTAL MONITORING AND CONTROL**

- ☑ Metering & Control Instrumentation
- ☑ Refractometers
- ☑ Pumps & Tubing
- ☑ Air, Soil & Water Monitors
- ☑ Industrial Water & Wastewater Treatment
- ☑ pH, Conductivity & Dissolved Oxygen Instruments